

Electronic Theodolite ET/ETL-02/05

Instruction Manual



PREFACE

Dear users:

Welcome to purchase and use our products and thank you for your confidence in our company's products!

It has been our target to innovate the international-level advanced surveying instrument since our company was established. All our surveying products are good-looking, reliable and multifunctional. Please read this operational manual carefully before usage of the instrument.

If you have any questions or suggestions, please do not hesitate to contact with the nearest sales department. We will do our best to serve you.

(In order to keep the instrument in good condition, we suggest that you should maintain it once annually at the sales department.)

The rights for revising technology and product specification are reserved by manufacturer and do not inform in advance.

CONTENTS

1. FEATURES	1
2. PREPARATIONS	2
2.1 PRECAUTIONS	2
2.2 PARTS	4
2.3 UNPACKING AND STORAGE	5
2.4 BATTERY AND CHARGER	6
2.5 ASSEMBLE AND DISASSEMBLE THE BASAL STUMP	8
3. KEYBOARD AND PANEL	10
3.1 KEYBOARD	10
3.2 PANEL	12
3.3 DISPLAY INFORMATION	13
4. INITIAL SETTING	14
4.1 SETTING ITEMS	14
4.2 SETTING METHOD	15
5. PREPARATION FOR SURVEY	18
5.1 CENTERING AND LEVELING	18
5.2 EYEPIECE ADJUSTMENT AND OBJECT SIGHTING	21
5.3 POWER ON OR OFF	23
5.4 VERTICAL INDEX ZERO SETTING (V 0SET)	24
6. BASIC SURVEY	26
6.1 OBSERVATION FROM NORMAL/REVERSED POSITION	26
6.2 HORIZONTAL ANGLE “0” SETTING (0 SET)	26
6.3 HORIZONTAL AND VERTICAL ANGLE MEASUREMENT	27
6.4 LOCK AND UNLOCK HORIZONTAL ANGLE (HOLD)	28
6.5 QUADRANT SOUND OF HORIZONTAL ANGLE SETTING	29

6.6 VERTICAL ANGLE “0” SETTING	29
6.7 MEASURE ZENITH DISTANCE AND VERTICAL ANGLE	30
6.8 SLOPE PERCENTAGE	31
6.9 REPEAT ANGLE MEASURE	32
6.10 OUTPUT ANGLE.....	34
6.11 SAVE ANGLE	34
6.12 MEASURE DISTANCE WITH STADIA	35
7. MEMORY	36
7.1 REVIEW INSTRUMENT’S SERIAL NUMBER	36
7.2 REVIEW ANGLE DATA IN MEMORY.....	36
7.3 CLEAR ANGLE DATA IN MEMORY.....	37
7.4 TRANSMIT DATA IN MEMORY TO SERIAL-PORT.....	38
7.5 DATA DOWNLOAD FROM NEW ET (SAMPLE WITH ACCESS PORT)	38
8. CONNECTION WITH CONTROLLER	40
9. INSPECTION AND ADJUSTMENT	40
9.1 PLATE VIAL.....	40
9.2 CIRCULAR VIAL.....	41
9.3 INCLINATION OF RETICLE	41
9.4 PERPENDICULARITY OF AIMING AXIS AND HORIZONTAL AXIS (2C)	42
9.5 AUTOMATIC COMPENSATION FOR VERTICAL INDEX ZEROING	44
9.6 VERTICAL INDEX DIFFERENCE AND SET TO ZERO.....	44
9.7 OPTICAL PLUMMET	46
9.8 OTHER ADJUSTMENT	47
10. SPECIFICATIONS	48
11. COMMON ERROR	50

12. ACCESSORIES52
ATTACHMENT 1:53
ATTACHMENT 2:56

1. FEATURES

Electronic theodolite of ET Series is designed by our company according to the concept of reasonable structure, smart appearance, reliable performance, various functions and easy operation. Not only it is easy to be realized all functions, but also it has the features below:

Able to Connect with Electronic Controller

Able to connect with most of the electronic controllers on the market to complete field data collection automatically.

Easy to Operate Key-press

It only has 6 keys which can realize all measure functions and can show distance data from range finder on monitor.

Can operate in dark place

Telescope's crosshairs and screen are equipped with illumination resource so that you can operate it in dark place.

2. PREPARATIONS

2.1 Precautions

(1) Avoid aiming the objective lens directly at the sun. When performing a measurement under sunshine, attach the filter to the objective lens.

(2) Avoid storage or usage at extremely high or low temperature and rapid changes of temperature (refer to working temperature range).

(3) Put the equipment into the carrying case for storage and place it in a dry area when it isn't used, do not subject it to vibrating, dust or high humidity.

(4) When the storage temperature and usage temperature is widely different, left the instrument in the case until it adapt to the surrounding temperature.

(5) When not in use for a long period, disassemble battery from ET and recharge the battery once per month.

(6) Put the instrument into its case when transport. Make sure to keep it from squeeze, clash and shake. Had better to put soft pad around the case during line-haul.

(7) Be sure to secure the instrument with one hand when mounting or removing from the tripod.

(8) When the exposed optical parts need to be cleaned, clean them with degreased cotton or lens-head paper gently, not with other clean tools.

(9) Be sure to clean the plastic parts and organic glass with water-soaked cloth, rather than chemical reagent.


(10) When the measure is finished, clean the surface of


your instrument with woolen cloth or fur brush. If it is wetted, never turn it on. Put it in the ventilation place for a period and rub it dry with clean cloth.

(11) Before operation, carefully inspect the power, functions and indexes of the instrument, initial setting and correction parameters.

(12) Do not disassemble the instrument by yourself, even if a malfunction is found, unless you are a professional.

2.2 Parts





2.3 Unpacking and Storage

Unpacking

Gently lay down the carrying case and set its cover upward, unlatch and open the case. Then, take the instrument out of the case.

Storage

Set the telescope close to vertical, and lightly tighten the telescope clamp screw. Align the white dot; place the instrument into the case with the white dot towards you. Close the case lid and lock the latch.

2.4 Battery and Charger

Assemble and Unassembled Battery


(1) Press the top button of the battery box to take off battery box.

(2) Insert the bottom edge of the battery into the slot of the equipment, and press the top button of the battery to lock.



Battery Information

Full battery can last for 8 to 10 hours continuously. The symbol




“” in the lower right corner of the screen displays power consumption message. Power consumption is as follows:




 and  indicate that energy is abundant.



 indicates there is a little energy left, and ready to replace or recharge it .



 twinkling indicates it will turn off in few minutes due to lack of energy, so stop operating and change battery ASAP.

Charging Battery

Please use special charger (10A) to recharge battery which is 10A, NiMH rechargeable. Insert the battery charger into the power source with 220V, then red light lights. Take off the on-board battery from the main body and connect the plug of the charger to charge socket on the battery. The indicating lamp is red indicates

the battery is recharging and it turns green in 6 hours means charge completes. Then remove the plug from the charge socket.

Warning: if the battery is placed improperly, it may cause explosion. Please deal with used battery according to manual.

Note on taking off the battery box!

- **Before you take off the battery box, make sure that the power of the instrument is turned off. Otherwise, the instrument can be damaged.**

Notes on recharging!

- **The charger has a built-in circuit for protection from overcharge. However, do not leave the charger plugged into the power after recharge is completed, because it will shorten the life of battery.**
- **Be sure to recharge the battery at a temperature of 0 °C ~ +45 °C. Charge may be abnormal beyond the specified temperature range.**
- **Prohibit the use of any already broken charger and battery.**

Notes on storage!

- **Rechargeable battery can be repeatedly recharged 300-500 times. Complete discharge of the battery may shorten its service life.**
 - **In order to maximum the battery life, be sure to recharge it once per month.**
 - **Do not place the battery in the hot and wet place and never make it short-circuit, or the battery will be destroyed.**
- Dispose and recycle battery properly according to local rules. Do not flip it into fire.**

2.5 Assemble and Disassemble the Basal Stump


Disassembly

If necessary, the instrument can be removed from the triangle basal stump. Firstly, loosen the triangle basal stump locking screw with a screw-driver. Then, turn the locking button about 180° in counter clockwise and take off the instrument from the triangle basal stump.

Installation


Fit directing convex mark to the directing concave of the tribrach. Put the three fixing feet into the holes respectively.

Turn the locking button clockwise about 180° to lock the instrument and the tribrach, then tighten the fixing screw of the locking button with a screw driver.



3. KEYBOARD AND PANEL

3.1 Keyboard



Display Information

Window

First Function


Symbol(upper)

Operation Key


Second Function

Symbol (lower)


Each key on the keyboard has double functions. Generally, instrument performs the first basic function. It will carry out the second extended function marked above the key after pressing FUNC.


 REC L/F	<p>Save key. Press it under shift mode, current angle twinkles twice, and then saved in memory. Press it to move cursor to left under special functional mode.</p> <p>Selection key for right or left horizontal angle. Press the key alternately to display two angles value accordingly</p>
--	---


<p>(▶)RPT</p> <p>HOLD</p>	<p>Repeated measure key. Press it to enter repeated state under shift mode. Press it to move cursor to right under special functional mode.</p> <p>The horizontal angle locking key. Press the key twice to lock the horizontal angle. Press the key again to return to unlock.</p>
<p>(▲)OUT</p> <p>0 SET</p>	<p>Output key. Press it under shift mode to output current angle to serial-port or to electronic controller.</p> <p>Decreasing key. Press it under special functional mode to move cursor down or decrease number.</p> <p>Horizontal angle “0” setting key. Press it twice to set horizontal angle 0.</p>
<p>(▼)MEAS</p> <p>V/%</p>	<p>Distance measure key. Press it under shift mode to make tracking measure once per second and precision is 0.01m (valid to connect with range finder).</p> <p>Press it continuously to display slope distance, horizontal distance, vertical distance and angle alternately. Increasing key. Press it in special functional mode to move cursor moves up or increase number.</p> <p>The shift key to display between vertical angle and slope percentage. Press it continuously to display the two types of value alternately.</p>

 FUNC	<p>Crosshairs and LCD illuminating key. Press it for 3 seconds to turn on light, and then press it for 3 seconds to turn off.</p> <p>Mode shift key. Press it continuously to enter different mode alternatively performing functions marked on the key or panel respectively. Press it under special functional mode to quit or confirm.</p>
POWER	<p>Power switch. Press the key to turn on; Press the key for over two seconds to turn off.</p>

3.2 Panel



Press-key	Function 1	Function 2
 REC L/F	Increment of right and left horizontal angle.	Save measured data
RPT HOLD	Hold horizontal angle	measure angle repeatedly

(▲)OUT OSET	Reset horizontal angle	Output measured data through serial-port
 FUNC	Select the second function	Illumination for LCD and graduation board
(▼)MEAS V/%	Vertical angle/slope angle percentage	Measure slope / horizontal/vertical distance
POWER	Power switch	



3.3 Display Information

Liquid Crystal Display is lined and commonly used symbols are all displayed in the following figure:

Angle or distance or tip is displayed in the two middle lines with 8 digits. Symbol or character in both right side and left side represents the content or unit of data.



Symbol	Content	Symbol	Content
VA	Vertical angle	%	Slope percentage
HA	Horizontal angle	G	Angle unit: division

H(R)	Level dextro-rotation increment(clockwise)		(Gon)(no symbol if unit is degree and mill)
H(L)	Level laevorotatory increment(clockwise)	m	Distance unit: meter
SD	Slope distance	ft	Distance unit: foot
HD	Horizontal distance		Batter capacity
VD	Vertical distance	HOLD	Lock mode
TILT	Tilt Compensator		Automatic close mark
RPT	Repeat mode	SHIFT	Shift to the second function

4. INITIAL SETTING

The instrument has many functions for selection in order to fit needs of result that different jobs require. Therefore, before using the instrument, we have to do initial setting according to different jobs' need.

4.1 Setting Items

- (1) Unit of angle measurement: 360° ,400gon, 6400mil (factory setting: 360°).
- (2) Vertical angle zero direction setting: horizontal zero orzenith zero (factory setting: zenith zero)
- (3) Automatic power off function: 30 minutes or 10 minutes

(factory setting: 30min).

(4) Minimum unit of angle displayed: 1 " or 5 "

(factory setting: 1 ").

(5) Vertical zero compensation choosing: Auto compensation or uncompensated (factory setting: auto compensation. This item is not available for those instruments that have no compensation with them.)

(6) Horizontal angle reading passes through the quadrants of 0° , 90° , 180° , 270° with the beeps or no beeps (factory setting: beep).

(7) Laser Plumb setting: For ET-02/05L only (factory setting: LASER 4)

(8) Current time setting

(factory setting: YYYY - MM-DD HH:MM).

4.2 Setting Method

(1) Press L/R to power on and loosen it until hearing three beeps. It enters initial setting mode state, monitor displays:




Eight digits in the next line of monitor respectively represent the content of initial setting as follows:

11111114

TO

00000000



DIGITALLY CODE

CONTENT CODE

CONTENT

(2) Press (◀) or (▶) key to move cursor to the figure digit needed to be modified.

(3) Press ▲ or ▼ key to alter figures displayed in the upper line of the monitor by code form.

(4) Repeat step (2) and (3) to set other items until all complete.

(5) Press **FUNC** to confirm after setting, and then it enters the interface of time setting.

(6) Time format: **Y-M-D H:M**, for example, **2007-01-01 00:00**, then press (◀) or (▶) key to move cursor to the figure digit needed to be modified.

(7) Press ▲ or ▼ key to alter figures displayed in the upper line of the monitor by code form.

(8) For example, set time as **2007-01-01 00:00**. Set year as 2007 firstly through ▲ or ▼, the same goes with month, day, hour and minute (note: unnecessary to set second).

(9) Press **FUNC** to confirm after setting, and save the new time to the instrument.

- After finishing initial settings are finished, the key **FUNC** must be pressed to confirm and save the setting, or the instrument will keep the original setting.
- During long-term usage, it is possible that the battery of real-time clock breaks off or lacks power, which causes a great difference between displayed time and current actual time, moreover, it is inconvenient to set time by the previous method (6) (7) and (8). (For example, the displayed time is 1234 caused by an unexpected reason but the real time is 2007, obviously using the former setting method will be troublesome.) There are another method: press **L/R** key for over 5s in the time setting interface, then the instrument will be automatically initialize time as 2007-01-01 00:00. Reuse the previous approaches to set time on the based on it.

5. PREPARATION FOR SURVEY

5.1 Centering and Leveling

Setting up the instrument and the tripod

(1) Adjust the tripod legs to obtain a height suitable for observation after selecting a solid ground.

(2) Hang a plumb bob on the hook of the tripod, and center over the station on the ground coarsely. At this time, set the tripod and fix the tripod legs firmly into the ground.

(3) Adjust the length of each leg to make the tripod head as level as possible. Fix the lock screws of the tripod legs, then put the instrument on the tripod head and lock with the screws.

Centering and leveling with the optical plummet

(1) Adjust the three leveling screws to make the bubble is(delete) in the center of the vial. Observe through the optical plummet eyepiece and rotate the eyepiece knob until the reticle can be seen clearly.

(2) Rotate the focusing knob of the optical plummet until the measurement land mark can be seen clearly and is in the same plane together with the mid-split graduation mark.

(3) Loosen the center screw of the tripod. Observe through the optical plummet, and shift the instrument based on the tripod, carefully level the instrument (avoid rotating the instrument) until the center mark coincides with the station.

(4) By adjusting any two leveling screws, the bubble is in the center of the vial.

(5) Observe through the optical plummet to confirm the land mark coincides with the center of the reticle. If not, repeat the step (3) and step (4) until they are coincided.

(6) Make sure that the land mark coincides with the center of the reticle , then lock the instrument.

Caution: do not touch the tripod legs after centering successfully to avoid altering the position.


Leveling precisely with plate vial

(1) Let the plate vial be in parallel with a line joining of any two of leveling screws. Adjust these two leveling screws in opposite directions at the same time to move the bubble to the center of the vial.

(2) Rotate the plate vial 90° around the vertical axis, make sure that the bubble is in the center by adjusting the third screw.

(3) Rotate the plate vial 90° , repeat (1) and (2), make sure that the bubble is in the center when plate vial is moved to any directions.

(4) Rotate the instrument 180° from position (1). If the bubble is in the center and always in the center while the plate vial is moved to any directions, the plate vial is set correctly and the instrument is leveled.




- Notice the relation between the directions of leveling screws' rotation and the bubble shifting direction.
- If the bubble does not remain in center in (4) , “ Adjustment of plate vial” is necessary. Refer to chapter (8.1) adjustment method.

5.2 Eyepiece Adjustment and Object Sighting

Eyepiece adjustment

- (1) Remove the telescope lens cover.
- (2) Sight the telescope at the sky and rotate the eyepiece ring until the reticle appears most clearly.

When looking into the eyepiece, avoid an intense observation to prevent parallax and eye fatigue. If it is hard to see the reticle due to poor brightness, press  key to illuminate it.




Object Sighting

- (1) Sight the telescope at the object by the collimator.
- (2) Look through the telescope eyepiece and finely adjust the focusing knob until the object is perfectly focused.
- (3) Use the clamp screw, then the tangent screws to sight at the object exactly. If focusing is correct, the reticle will not move related to the object, even when you move your eye slightly around.

- Turn the focusing knob clockwise to focus a near object. Turn the knob counterclockwise to focus a far object.
- If do not adjust (3) well , parallax may distort the relation between the object and reticle, resulting in the observation error.
- When aligning to an object using the tangent screw, always align by rotating the screw clockwise. If the screw is overturned, turn it back to the original position and sight the object by rotating the screw clockwise again.
- Even when vertical angle measurement is not required, it is recommended that the object be placed to the center of the reticle as exactly as possible.


5.3 Power On or Off

Key style power switch

operation	display
<p>Press [POWER] key and hold it until all the symbols are displayed. The power is on.</p>	 <p>HD SD VD 8888-88-88 88:88 0 V 8888.8888" %G (TILT) mft H: 8888.8888" BAT (HOLD) (RPT) (SHIFT)</p>
<p>Horizontal angle will be displayed in 2 seconds and then the measurement can be started.</p>	 <p>2007-03-21 08:38 V b (TILT) H: 108°40' 10"</p>
<p>Press and hold [POWER] key over 2 seconds to turn power off.</p>	 <p>OFF</p>

- When the power is turned on, the displayed angle value is the value saved in memory last time. If the displayed angle is no use anymore, do the horizontal zero setting.
- If no operation is performed in 10 or 30 minutes. The power will be turned off automatically due to “power auto off function” and the horizontal angle will be stored in memory automatically.

5.4 Vertical Index Zero Setting (V 0SET)

operation	display
<p>Turn on the instrument. Displaying “b” means that the vertical axis is not vertical. If the instrument is leveled exactly, “b” will disappear. After the instrument is leveled exactly, turn on the instrument and it displays “V 0SET” which means that the vertical index has been set to zero.</p> <p>Turn the telescope up and down in normal position in horizontal direction. Vertical index zero is set when the telescope passes level and the vertical angle is displayed. The instrument is now ready for angle measurement.</p>	

- **If vertical index automatic compensation set is used, the vertical index can be compensated. When the vertical index is beyond the designed criterion, “b” will be displayed. Level the instrument precisely until “b” disappears. Then the instrument gets its breath again.**
- **If no operation is performed in 10 or 30 minutes. The power will be turned off automatically due to “power auto off function” and the horizontal angle will be stored in memory automatically.**

6. BASIC SURVEY

6.1 Observation from Normal/Reversed Position

“Normal position telescope” means that the shaft disc is on the left side of the telescope when observers face eyepiece lens (see figure). “Reversed position telescope” means that the shaft disc is on the right side of the telescope when observers face eyepiece lens. In angle measuring, we should get the measuring result through averaging the two values got from both observations above. And it can eliminate the influence caused by the instrument’s systematic errors effectively. Therefore, when doing horizontal and vertical observation, rotate telescope 180° to do reversed position observation after finishing normal position observation



Normal Position Observation



Reversed Position Observation

6.2 Horizontal Angle “0” Setting (0 SET)

Sight reticle of the telescope at object A, press 0 SET twice to set the horizontal angle as $0^\circ 00'00''$. For instance,


sight at object A displaying \rightarrow HR $50^{\circ} 10'20''$ \rightarrow press 0
 SET twice \rightarrow displaying HR $0^{\circ} 00'00''$

- [OSET] key is valid only for horizontal angle.
- Horizontal angle can be set to “0” any time except when [HOLD] key is set. If [OSET] is pressed by mistake during operation, there is no effect unless the key is pressed again. When the beep stops, the instrument is ready for next operation.


6.3 Horizontal and Vertical Angle Measurement

(1) Set horizontal angle dextro-rotation and vertical angle as zero Turn the instrument clockwise to sight at the object A exactly, press OSET twice to set horizontal angle to $0^{\circ} 0'00''$ as the initial zero direction. The steps and displaying contents are as follows:

Vertical angle (zenith distance) in A direction



Turn the instrument clockwise Horizontal angle is set to zero in A direction



Dextro-rotation horizontal angle in AB direction

(2) Press R/L to change horizontal angle from right to left mode. Turn the instrument counterclockwise (HL), sight at the object A exactly, press OSET twice to set horizontal angle to $0^{\circ} 00'00''$ as the initial zero direction. The displayed results are the same as (1). Turn the instrument counterclockwise (HL) and sight at objects B. The displayed contents are the followings:

V	91°05'10"
HR	309°49'40"

Vertical .angle (zenith distance.)
in B direction
Horizontal .angle left in AB direction.

6.4 Lock and Unlock Horizontal Angle (HOLD)

During horizontal angle observation, if you want to retain the measured value, press [HOLD] twice. Once horizontal angle is locked, "HRL" is displayed and the horizontal angle value will not change even if you rotate the instrument. When you sight at the needed direction, press [HOLD] again to release lock function. Then the horizontal angle value is the original locked value.

- [HOLD] is invalid for vertical angle or distance.
- If [HOLD] key is pressed by mistake during operation, it does not matter unless the key is pressed again. When the beep stops, next operation can be continued.

6.5 Quadrant Sound of Horizontal Angle Setting

(1) Sight at the first objective and then press [O SET] twice to set the horizontal angle to zero.

(2) Turn the instrument around the vertical axis about 90° until the beep starts ,displaying $HR89^\circ 59'20''$


(3) Lock the instrument by the clamp screw and set the horizontal angle to $90^\circ 00'00''$ by the tangent screw. Then, fix the quadrant target direction by the telescope reticle.

(4) determine the quadrant target direction of 180° and 270° by the same method.



- The beep beeps when the reading passes any of 0° , 90° , 180° , 270° . It beeps in the range of $\pm 1'$ -- $\pm 20'$.
- The beep can be canceled in the initial setting.

6.6 Vertical Angle “0” Setting

Before starting operation, initial setting in vertical angle is doing according to operation’s requirement selecting zenith 0/horizontal 0(Refer to 4.2 initial setting.).Vertical disk structures of two setting



6.7 Measure Zenith Distance and Vertical Angle



operation	display
<p>(1) Zenith distance: If vertical angle is 0° in zenith direction, then the vertical angle measured in this way is the zenith distance. (shown as the figure)</p> <p>Zenith distance = $(L + 360^\circ - R) / 2$</p> <p>Index difference = $(L + R - 360^\circ) / 2$</p> <p>(2) Vertical angle: If vertical angle is 0° in horizontal direction, then the vertical angle measured in this way is the perpendicular angle. (See the figure).</p> <p>Vertical angle = $(L \pm 180^\circ - R) / 2$</p> <p>Index difference = $(L + R - 180^\circ) / 2$</p>	 <p>θ is zenith distance</p>  <p>θ is perpendicular angle</p>

● If the absolute value of index difference is larger than $10''$ (i.e. $|I| \geq 10''$), adjustment should be made as introduced in chapter 8.5 and 8.6 in this manual.

6.8 Slope Percentage

The vertical angle can be converted into slope percentage in angle measurement mode. Press V/% and the display shows vertical angle or grade percentage alternately.

$$\text{Slope \%} = H/D \times 100\%$$







The range of slope percentage should be between the horizon direction and $\pm 45^\circ$ ($\pm 50\%$). Otherwise the instrument will display over EEE.EEE%

6.9 Repeat Angle Measure

Turn on the instrument in angle measure mode

Operation	Display
① Press FUNC key.	
② Press RPT key to enter repeat measure mode. ③ Sight at the first target A.	
④ Press L/R key to set the reading of the first target as 0°00'00\".	
⑤ Sight at the second target B with horizontal tangent screw and clamp screw.	
⑥ Press HOLD key to hold and save it into the instrument.	

<p>⑦ Sight at the target A again with horizontal tangent screw and clamp screw.</p>	
<p>⑧ Press L/R key to set the first target as 0° 00' 00" .</p>	
<p>⑨ Sight at the second target B again with horizontal tangent screw and clamp screw.</p>	
<p>⑩ Press HOLD key to hold and save it into the instrument. Average angle reading appears. Repeat steps ⑥ to ⑩ to measure with the number you want . Press FUNC to exit after completion.</p>	
<p>※ The number of repeat measure in repeat measure mode is limited to 8. If exceeds 8 times, it will quit automatically.</p> <p>※ Sight at the target and begin with step ③ when doing repeat measure again.</p> <p>※ Press FUNC key to quit repeat measure mode and return to angle measure mode.</p>	

6.10 Output Angle

Turn on and enter angle measure mode, and press FUNC key to enter the second function selection mode. Press OUT key to transmit the current angle to serial-port or electronic controller (baud rate is 1200), “-----” will be displayed on the screen for one second after successful transmission.

6.11 Save Angle

Turn on and enter angle measure mode, press FUNC key to enter the second function selection mode, and then press REC to save angle. At that time, the current angle glitters twice, which represents it has been saved to the memory. If you want to save angle again, press REC key after regulating an angle.

If you want to review saved angle data, please refer to Chapter 7 about memory.

Notice: the instrument only supplies 256 groups of angle data (each group of angle data includes one vertical angle and one horizontal angle). If angle data saved exceeds 256 groups, “FULL” will be displayed on the interface which means that memory is full. Users then need to clear manually to resave angle, please refer to the chapter about memory for more details.

6.12 Measure Distance with Stadia


The distance from the measuring object to the instrument can be obtained by using the stadia hair of the telescope with the accuracy $\leq 0.4\%D$.

Set up the instrument at point A and put the surveying rod on target point B.

Read the intercept d of apparent lines from up and down from the reticle on the survey rod.

The horizontal distance (D) between A and B can be calculated with the formula below:


$$L = 100 \times d$$




- The precision of the distance measurement is not very high. Do not use this method when high precision is required.



7. MEMORY

7.1 Review Instrument's Serial Number

Operation	Display
<p>① Press FUNC key and POWER key to turn on. After beeping three times, it enters memory reviewing interface. What displayed on the main interface is instrument's serial number that is the same as the number printed on the instrument's body, for instance, T53056, shown as the right picture. Hope users check it carefully to protect their own interests.</p> <p>② Press FUNC to quit.</p>	

7.2 Review Angle Data in Memory

Operation	display
<p>① Press FUNC key and POWER key to turn on. After beeping three times, it enters memory Review interface.</p>	

<p>② Press V/% key to display angle data in memory mode. N. 000 means there is no angle data in memory.</p>	
<p>③ N. 001 means there are angle data in memory, so we can use (◀) and (▶) to select angle in memory to look over. Use ▲ or ▼ to select vertical angle and horizontal angle displayed in the second line. What shown in the right picture is vertical angle data of the 4th group in memory.</p>	
<p>④ press FUNC to quit and return to review instrument's serial number. Press FUNC again to quit memory mode and return to angle measure mode.</p>	

7.3 Clear Angle Data in Memory

After step(7.2) to enter into angle data reviewing mode, press ▼ for over 5 seconds, it beeps three times, and “CLEAR” appears on the interface, which represents all angle data in memory are cleared.

(Note: memory can save at most 256 groups of

data and system will hint you when storage is full. Then users should transmit the useful angle in memory through serial-port and clear data in memory manually.

7.4 Transmit Data in Memory to Serial-port

After step(7.2) to enter into angle data reviewing mode, the angle data is transmitted though serial-port when users press or ▲ (◀) (▶)review the angle data in the memory (delete)(“-----” instantly appears in the second line illustrate that the current angle has been transmitted through serial-port, which can be reviewed by serial-port facility such as Serial-port Genius. Baud rate is 9600.)

In addition, the function to transmit all angle data to serial-port at a time is furnished. In the light of steps of examining angle data in memory, press ▲ in examining angle interface for over 5 seconds, it beeps three times which means it starts to send all angle data to serial-port. Baud rate is 9600 and sending time depends on the number of angle in memory.

7.5 Data Download from New ET (Sample with Access port)

Step:

1. Connect series port on ET with the CE-203U to the series port or USB of PC.
2. If connect PC with USB port, pleas install the drive firstly.

Open the file like ‘Scomassistant’ or ‘AccessPort’ (example:

AccessPort)



3. Set Baud rate to 9600 and select the correct COM



4. Refer to '7.2 Examine Angle Data in Memory'

Press (◀)(▶) or ▲ ▼ to review angle data in memory which is transmitted to PC through serial-port at the same time one by one.

press ▲ in examining angle interface for over 5 seconds, it beeps three times which means it starts to send all angle data to serial-port. Baud rate is 9600 and sending time depends on the number of angle in memory.

5. Save the data transmitted to the program, then you can edit.

If you do not need the data, you can clear them.

8. CONNECTION WITH CONTROLLER

Connection electronic theodolite with electronic controller

There is a data output and input port that locates at the lower side of optical plummet of ET/DT—02/05/05B electronic theodolite. Transmit measured data to electronic controller with CE-201 cable.

9. INSPECTION AND ADJUSTMENT

9.1 Plate Vial

Inspection

Refer to Chapter 5.1 about “Leveling with Plate Vial”.

Adjustment

(1) Check the step(4) in inspection. If the bubble of the plate vial drifts away from the center, bring it half excursion back to the center by adjusting the two leveling hand wheels which are parallel to the plate vial.

(2) Correcting the remaining half by turning the bubble adjusting screw with the adjusting pin.

(3) Confirm that the bubble does not move away from the center when the instrument is rotated to 180° . If not, repeat the steps above.

(4) Turn the instrument by around 90° and adjust the third screw to center the bubble in the vial. Repeat inspection and adjustment steps until the bubble remains in center in any directions.

9.2 Circular Vial

Inspection

It is not necessary to adjust if the bubble of the circular vial is in the center after inspecting and adjusting of the plate vial.

Adjustment

If the bubble of the circular vial is not in the center, bring the bubble to the center by turning adjusting screw with adjusting pin or adjustable wrench. When adjusting, first loosen one or two screws on the opposite of the offset direction, then, tighten the adjusting screw in the offset direction to bring the bubble to the center. When the bubble stays in the center, keep the fastening strength of the three screws in uniformity.

9.3 Inclination of Reticle

Inspection


(1) Level the instrument and select a target A in the line of sight of telescope, sight at A through the center of reticle of graduation board and lock the horizontal and vertical clamp screws.

(2) Move point A to the edge (point A') of the field of view by rotating the vertical tangent screw.

(3) No adjustment is necessary if point A moves

along the vertical line of the reticle.

If point A' deviates the vertical line of the reticle, It proof what reticle is tilted, so we need to do correction on graduation board.



Adjustment

(1) Firstly, remove the eyepiece cover between eyepiece and focusing screw and you can see four screws.

(2) Loosen the four reticle adjusting screws equally with a screwdriver. Rotate the reticle around the aiming axis, and align the vertical line of the reticle with point A'.

(3) Rotate the fastened screw equally. Repeat the inspection and adjustment to confirm the result.

(4) Remount the eyepiece cover.

9.4 Perpendicularity of Aiming Axis and Horizontal Axis (2C)

Inspection

(1) Set an object A at a far distance, the same height as the instrument, level and center the instrument and turn on

the power.

(2) Sight at the object A in normal position and read the horizontal angle value. (Suppose that: $L=10^{\circ}13'10''$).

(3) Loosen vertical and horizontal clamp screws, and reverse the telescope. Sight at the object A in reversed position and read the horizontal angle value. (Suppose that : $R=190^{\circ}13'40''$)

$$(4) 2C = |L - (R \pm 180^{\circ})| = |10^{\circ}13'10'' - (190^{\circ}13'40'' - 180^{\circ})| = 30'' \quad \text{then } 30'' \geq 20''.$$

That means adjustment is needed.


Adjustment

(1) To eliminate the big error, use the horizontal tangent screw to adjust the horizontal reading to the deduce a C: $R+C=190^{\circ}13'40''-15''=190^{\circ}13'25''$.

(2) Take off the cover of the reticle between eyepiece and focusing screw. Adjust the two adjusting screws by loosening one and tightening the other one. Move the reticle to sight at the object A exactly.

(3) Repeat inspection and adjustment until $|2C| < 20''$.

(4) Remount the cover of reticle back.



9.5 Automatic Compensation for Vertical Index zeroing Inspection

Liquid condenser automatic compensation set is used for vertical index zeroing compensation. We can check if the function works well by the following method.

(1) Mount and level the instrument and make the telescope parallel with the line connecting the center of the instrument to any one of the screws. Then, lock the horizontal clamp screw.

(2) Zero the vertical index after turning on the power. Lock the vertical clamp screw and the instrument displays current vertical angle value.

(3) Rotate the above screw in a direction slowly to about 10mm circumference. The displayed value will change correspondingly and then disappear and display the message “b”. It indicate that vertical axis inclines is more than 3’ at this time and exceeds the designed compensation range. When you rotate the above screw reversely to the original position, the instrument displays the vertical angle again which means that the vertical index difference compensation function works well. (Experiment repeatedly and observe its change at critical position.)

<p>● ET-10/20 model instrument does not have vertical zero automatic compensation set.</p>

9.6 Vertical Index Difference and Set to Zero

After making adjustments as described in 9-3 and 9-5, make the inspection as follows:

Inspection

Set up the instrument and turn on. Sight at a reference A and obtain the vertical angle (Left).

Reverse the telescope and sight at the object A again and obtain the vertical angle (Right).

If vertical angle is zero at zenith, then, $I=(L+R-360^\circ)/2$; If vertical angle is zero at horizon, then, $I=(L+R-180^\circ)/2$ or $(L+R-540^\circ)/2$.

If $|i| \geq 10''$, vertical index zeroing should be set again.

Adjustment (Setting up vertical index zeroing)

(1) After leveling the instrument, press **0SET** to turn on and hold it until three beeps. The instrument displays that:

V	90°	20'	30''
C	SET	--	1

(2) Rotate the telescope around near the horizontal direction to sight at a clear and stable objective A, which is nearly the same height as the instrument. Press **0SET** key, displaying:

V	90°	20'	30''
C	SET	--	2

(3) Reverse the telescope and sight at the object A again. Press **0SET** key to finish vertical index zeroing setting. The instrument returns to angle measurement mode.

(4) Repeat the inspection procedures. If $|I| \geq 10''$, check if anything is wrong in operation and repeat the adjustment

again.

(5) If the vertical index difference does not meet the standard yet after being adjusted repeatedly, the instrument should be sent to factory to be repaired.

● **The vertical angle displayed in the process of zeroing setting is not compensated and corrected, so it cannot be used formally but as a reference value.**

9.7 Optical Plummet

Inspection

- (1) Set the instrument on the tripod, and place a piece of white paper with a cross on the ground right under the instrument.
- (2) Adjust the optical plummet focus, and move the paper to make the crosshair to the center of the field of view.
- (3) Adjust the leveling screws to make the center mark of the optical plummet coincide with the intersecting point of the reticle.
- (4) Rotate the instrument around the vertical axis at every 90° and observe that whether the center mark position coincides with the intersecting point of the reticle.
- (5) If the center mark always coincides with intersecting point when rotating the instrument, no adjustment is necessary. Otherwise, the following adjustment is needed.



Adjustment

- (1) Take off the protecting cover between the optical plummet eyepiece and focusing knob.
- (2) when the instrument moves at every 90° , mark the place of the center mark On the white paper with a crosshairs, so the paper have four point A,B,C and D.
- (3) Join the diagonals with lines (A, C and B, D).The intersecting point of the two lines is called "0".
- (4) Adjust the four correction screws of the optical plummet by an adjusting pin until the center mark coincides with the above intersecting point.
- (5) Repeat the above inspecting and adjusting steps until it is up to the requirement.
- (6) Remount the protecting cover.

9.8 Other Adjustment

If the leveling screw loses, adjust it with two correction screws on the basal plate. Tighten the screws till they are fit.

10. SPECIFICATIONS

Telescope	
Image	Erect image
Magnification	30X
Effective aperture	45mm
Resolution	3"
Field of view	1°30'
Shortest stadia	1.4m
Stadia multiplication constant	100
Stadia additive constant	0
Stadia precision	≤0.40%L
Tube length	157mm
Angle measurement	
Angle measurement mode	Absolute encoding mode
Diameter of raster disks (vertical and horizontal)	79mm
Minimum display reading	1" or 5", optional
Detection mode	Horizontal angle: dual
	Vertical angle : dual
Angle measurement Unit	360 ° 400gon/6400mil, optional
Precision	ET-02: 2", ET -05: 5"

Leveling vials	
Plate vial	30"/2mm
Circular vial	8'/2mm
Vertical compensator	
System	liquid condenser mode, optional
Working range	$\pm 3'$
Precision	$\pm 3''$
Optical plummet	
Image	Erect image
Magnification	3X
Focusing range	0.5 $\sim\infty$
Field of view	5 $^{\circ}$
System	
Display	LCD, four lines, line segment
Internal Memory	Space for 256 pairs of H. & V. angle
Data input/output	
Interface	RS --232C
On-board battery	
Power source	Rechargeable NI-H Battery
Voltage	DC 4.8V
Continuous working hours	8h
Working environment	
Working Temperature	-20 $^{\circ}\sim+45^{\circ}$
Dimensions and weight	
Overall dimensions	160X150X330mm

Instrument weight	5.2kg
-------------------	-------

11. COMMON ERROR

When operating the instrument improperly or circuit within the equipment has problems, error codes will be displayed on the screen, whose contents and solving methods are listed as follows:

ErrorCode	Meaning and Solution
Err 01	Something wrong with horizontal disk measurement. Turn off the instrument, then power on,if Err01 still appears, send it to be repaired.
Err 02	Telescope is rotated too fast .Press V/% , after displaying “V 0SET”, show vertical disk index Return to 0 (namely rotate telescope up and down near the horizontal position when left disk).
Err 03	Collimator is rotated too fast .Press 0 SET to reset.
Err 04	Something wrong with vertical photo-electric convertor (I). Send it to be repaired.
Err 05	Something wrong with horizontal photo-electric convertor (I). Send it to be repaired.
Err 06	Something wrong with horizontal photo-electric convertor (II). Send it to be repaired.
Err 07	Something wrong with vertical photo-electric convertor (II). Send it to be repaired.

Err 08	Something wrong with vertical disk. Turn off and level the instrument. If Err 08 still appears after power on, send it to be repaired.
Err 20	Something wrong with 0set of vertical disk index. Operate again according to chapter 8.6. If Err 20 still appears, press HOLD 、 OSET 、 HOLD to force setting.
Err 21	Exceeded zero-point of electronic compensator of vertical angle. Turn off and level the instrument. If Err 21 still appears after power on, send it to be repaired.

- **When errors appear, check the instrument and your operation steps. If you confirm that something is wrong with the instrument, send it to factory to be repaired.**

12. ACCESSORIES

Standard Configuration

• Carrying Cass	1
• Main Body	1
• On-Board Battery	1
• Charger	1
• AA Battery Box	1
• Plumb	1
• Correction Pin	2
• Fur Brush	1
• Screwdriver	1
• Hexagon Wrench	2
• Cloth	1
• Dryer	1
• Certificate	1
• Operation Manual	1

Optional Configuration

• Boluo Board	1
• Diagonal Eyepiece	1
• Solar Filter	1

Attachment 1:

Note: This attachment is **only** applicable to laser theodolites.

The feature of laser theodolites

The laser theodolites are instruments which build a laser system in the optical telescope.

Laser function

With the advantage of visible laser line, the instrument can be applied conveniently to constructions.

Caution

! Be careful. Laser is harmful to eyes! **Do not** put off prevention glasses when observing through eyepieces!

Turn on and turn off the laser

Press the button **FUNC** for 3 seconds to turn on the illumination and the laser is lighted simultaneously. Again, continuously press the button **FUNC** for 3 seconds to turn off the illumination and the laser shut down at the same time.

Adjustment of laser

Adjustment method:

Step 1. Settle a cross mark '+' in a place 20 meters away from the telescope.


Step 2. Aim the telescope to the mark and focus it clearly. Be sure that the center of cross hair of the telescope must be coincided with the center of the mark.

Step 3. Adjust the focusing handwheel slightly and confirm if the laser facula turn to be the minimum size. The cross mark “+” should be the most clear through eyepieces if the facula is in the smallest status.

If the cross hair cannot be seen clearly the adjustment pad must be changed.(These process has been done well in the factory. So do this step only when the laser tube be changed)

Step 4. Adjust adjusting screws to make the center of facula coincide with the center of mark. Then observe the telescope and the center of cross hair of the telescope must also be coincided with the center of the mark.

Repeat the processes above for several times to achieve the best status.



Correction pad

Adjusting screw

Requirement

- (1) laser beam and collimation axis coaxial
- (2) laser emit point and the telescope's cross hair conjugate in center

That is to say when the aim is the clearest observed from telescope, the laser convergence point emit to the center of the aim and the convergence point should be the smallest.

Laser technology instruction

Laser tube	
Wave length	630mm---670mm
Power	5mW
The maximum measurement distance	180m(daylight without sunlight)
Center facula diameter	$\leq \Phi 5\text{mm}/100\text{m}$
Non-coaxial error of laser axis and collimation axis	$\leq 10''$

Attachment 2:

Note: This attachment is **only** applicable to the theodolites with laser plummet.

Feature of the laser plummet

The laser plummet set of the ET series theodolites features the adjustable laser intensity, quick switch etc.

Switch on/off the laser plummet

After entering to the main interface, continuously press the button **L/R** more the 3 seconds . The instrument performs the laser plummet function automatically. Again, continuously press the button **L/R** more the 3 seconds the function will be shut down.

Setting of the laser plummet intensity

Continuously press the button **L/R** to power on the instrument and loose the buttons after 3 beeps to enter into the setting interface. Find out the setting option of message “LASER”(the most right) and then press up or down to adjust the digit. There are 5 alternative digits: 0 indicates that the intensity is 0(0 is the most weakness and 4 is the most intensity). Press function to save after setting, or it is invalid.

Note:

1. The intensity default setting is 4. It means the most powerful and users can adjust it weaker according to need.

2. When adjusting the intensity, users had better do not select digit 0, or the function seems to be shut down.

