CONTENTS

1.1	FEATURES	1
2.	PREPARATION	2
	2.1 Precautions	2
	2.2 Appearance	3
	2.3 Unpacking and Storage of the Instrument	5
	2.4 Instrument Set Up	5
	2.5 Battery Removal & Insertion – Information and Recharging	7
	2.6 Assemble and Disassemble the Tribrach	8
	2.7 Eyepiece Adjustment and Object Sighting	9
	2.8 Power On & Off	9
	2.9 How to Enter Alphanumeric Characters	.10
3.	FUNCTION KEY AND DISPLAY	12
	3.1 Operating Key	.12
	3.2 Function Key	.13
	3.3 Star-key	.16
4.	INITIAL SETTINGS	18
	4.1 Setting the Temperature and Atmospheric Pressure	.18
	4.2 Setting of the Atmospheric Correction	.19
	4.3 Setting of the Prism Constant	.21
5.	ANGLE MEASUREMENT	22
	5.1 Measuring Horizontal Angle Right and Vertical Angles	.22
	5.2 Switching Horizontal Angle (Right/Left)	.23
	5.3 Setting of the Horizontal Angle	.24
	5.3.1 Setting by Holding the Angle	24
	5.3.2 Setting the Horizontal Angle from the Keypad	25

5.4 Vertical Angle Percent Grade (%) Mode. 26 5.5 Setting the Initial Zenith Angle. 27 6.DISTANCE MEASUREMENT. 28 6.1 Setting of the Atmospheric Correction 28 6.2 Setting of the Correction for Prism Constant. 28 6.3 Distance Measurement (Continuous Measurement) 28 6.4 Changing the Distance Measurement Mode. 29 6.5 Stake Out(S.O.). 31 7.COORDINATE MEASUREMENT. 33 7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height). 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement. 43 8.4 Column Offset Measurement (MLM). 49 8.6 Remote Elevation Measurement (REM) 54 9.5 Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 58 9.4 Reference Line Stakeout.		
5.5 Setting the Initial Zenith Angle. 27 6.DISTANCE MEASUREMENT. 28 6.1 Setting of the Atmospheric Correction 28 6.2 Setting of the Correction for Prism Constant. 28 6.3 Distance Measurement (Continuous Measurement). 28 6.4 Changing the Distance Measurement Mode. 29 6.5 Stake Out(S.O.). 31 7.COORDINATE MEASUREMENT. 33 7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height). 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement (MLM). 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 63 10.CALCULATION66 63	5.4 Vertical Angle Percent Grade (%) Mode	26
6.DISTANCE MEASUREMENT	5.5 Setting the Initial Zenith Angle	27
6.1 Setting of the Atmospheric Correction 28 6.2 Setting of the Correction for Prism Constant. 28 6.3 Distance Measurement (Continuous Measurement) 28 6.4 Changing the Distance Measurement Mode. 29 6.5 Stake Out(S.O.) 31 7.COORDINATE MEASUREMENT	6.DISTANCE MEASUREMENT	28
6.2 Setting of the Correction for Prism Constant. 28 6.3 Distance Measurement (Continuous Measurement). 28 6.4 Changing the Distance Measurement Mode. 29 6.5 Stake Out(S.O.). 31 7.COORDINATE MEASUREMENT	6.1 Setting of the Atmospheric Correction	28
6.3 Distance Measurement (Continuous Measurement) 28 6.4 Changing the Distance Measurement Mode. 29 6.5 Stake Out(S.O.) 31 7.COORDINATE MEASUREMENT. 33 7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height) 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement. 42 8.3 Plane Offset Measurement (MLM) 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 63 10.4 Cal XYZ(Coordinate Calculation) 67	6.2 Setting of the Correction for Prism Constant	28
6.4 Changing the Distance Measurement Mode. .29 6.5 Stake Out(S.O.). .31 7.COORDINATE MEASUREMENT. .33 7.1 Procedures of Coordinate Measurement. .33 7.2 Setting Coordinate Values of Station Point. .35 7.3 Setting Height of the Instrument. .36 7.4 Setting Height of Target (Prism Height). .37 8.DATA COLLECTION. .39 8.1 Point Collect. .40 8.2 Distance Offset Measurement. .42 8.3 Plane Offset Measurement. .43 8.4 Column Offset Measurement (MLM). .49 8.5 Missing Line Measurement (MLM). .49 8.6 Remote Elevation Measurement (REM) .54 9.Stake Out. .57 9.1 Choose data file. .58 9.2 Coordinate stake out. .58 9.3 Angle/distance stakeout. .61 9.4 Reference Line Stakeout. .63 10.1 Cal XYZ(Coordinate Calculation). .67	6.3 Distance Measurement (Continuous Measurement)	28
6.5 Stake Out(S.O.) 31 7.COORDINATE MEASUREMENT. 33 7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height). 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement. 43 8.4 Column Offset Measurement (MLM). 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 61 9.4 Reference Line Stakeout. 63 10.1 Cal XYZ(Coordinate Calculation) 67	6.4 Changing the Distance Measurement Mode	29
7.COORDINATE MEASUREMENT. 33 7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height). 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement. 42 8.4 Column Offset Measurement. 47 8.5 Missing Line Measurement (MLM). 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 61 9.4 Reference Line Stakeout. 63 10.CALCULATION66 63	6.5 Stake Out(S.O.)	31
7.1 Procedures of Coordinate Measurement. 33 7.2 Setting Coordinate Values of Station Point. 35 7.3 Setting Height of the Instrument. 36 7.4 Setting Height of Target (Prism Height). 37 8.DATA COLLECTION. 39 8.1 Point Collect. 40 8.2 Distance Offset Measurement. 42 8.3 Plane Offset Measurement. 43 8.4 Column Offset Measurement (MLM). 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out. 57 9.1 Choose data file. 58 9.2 Coordinate stake out. 58 9.3 Angle/distance stakeout. 61 9.4 Reference Line Stakeout. 63 10.1 Cal.XYZ(Coordinate Calculation) 67	7.COORDINATE MEASUREMENT	33
7.2 Setting Coordinate Values of Station Point	7.1 Procedures of Coordinate Measurement	33
7.3 Setting Height of the Instrument	7.2 Setting Coordinate Values of Station Point	35
7.4 Setting Height of Target (Prism Height) 37 8.DATA COLLECTION 39 8.1 Point Collect 40 8.2 Distance Offset Measurement 42 8.3 Plane Offset Measurement 43 8.4 Column Offset Measurement 47 8.5 Missing Line Measurement (MLM) 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out 57 9.1 Choose data file 58 9.2 Coordinate stake out 58 9.3 Angle/distance stakeout 61 9.4 Reference Line Stakeout 63 10.1 Cal XYZ(Coordinate Calculation) 67	7.3 Setting Height of the Instrument	36
8.DATA COLLECTION 39 8.1 Point Collect 40 8.2 Distance Offset Measurement 42 8.3 Plane Offset Measurement 43 8.4 Column Offset Measurement 47 8.5 Missing Line Measurement (MLM) 49 8.6 Remote Elevation Measurement (REM) 54 9.Stake Out 57 9.1 Choose data file 58 9.2 Coordinate stake out 58 9.3 Angle/distance stakeout 61 9.4 Reference Line Stakeout 63 10.1 Cal XYZ(Coordinate Calculation) 67	7.4 Setting Height of Target (Prism Height)	37
8.1 Point Collect	8.DATA COLLECTION	39
8.2 Distance Offset Measurement	8.1 Point Collect	40
8.3 Plane Offset Measurement	8.2 Distance Offset Measurement	42
8.4 Column Offset Measurement	8.3 Plane Offset Measurement	43
 8.5 Missing Line Measurement (MLM)	8.4 Column Offset Measurement	47
8.6 Remote Elevation Measurement (REM)	8.5 Missing Line Measurement (MLM)	49
9.Stake Out	8.6 Remote Elevation Measurement (REM)	54
9.1 Choose data file	9.Stake Out	57
9.2 Coordinate stake out	9.1 Choose data file	
9.3 Angle/distance stakeout	9.2 Coordinate stake out	58
9.4 Reference Line Stakeout	9.3 Angle/distance stakeout	61
10.CALCULATION66	9.4 Reference Line Stakeout	63
10.1 Cal XYZ(Coordinate Calculation)	10.CALCULATION66	
2012 0001010000000000000000000000000000	10.1 Cal.XYZ(Coordinate Calculation)	67

	10.2 Coordinate inverse calculation	
	10.3 Area/ Perimeter	69
	10.4 Point to Line Inverse	71
11.	PROGRAM	73
	11.1 Road	74
	11.1.1 Horizontal Alignment Data	75
	11.1.2 Vertical Alignment Data	79
	11.1.3 Road Stake Out	81
	11.1.4 Calculation	83
	11.1.5 Road select	83
12.	Set Station	84
	12.1 Known Point	84
	12.2Resection	89
	12.3 Point to Line Measurement	90
	12.4 Elevation Transmit	92
	12.5 Backsight Check	94
13.	DATA	95
	13.1 File Management	96
	13.1.1 Deleting a File	96
	13.1.2Built a New File	97
	13.1.3Find a File	98
	13.1.4 Edit File	
	13.2 Measurement Data	100
	13.3 Coordinate Data	101
	13.4 Code Data	
	13.5 Data Export	102
	13.6 Data Import	

13.7 Memory	103
13.8 Format	104
14.SETTING	105
14.1Measure Parameter	106
14.1.1Angle Parameter	
14.1.2 Distance Setting	106
14.1.3 Coordinate Settings	
14.2 Unit Setting	108
14.3 Serial Comm Setting	
14.4 Backlight Setting	109
14.5 Time/date Setting	110
14.6 Other Setting	110
15.CHECK AND ADJUSTMENT	111
15.1 Plate Vial	111
15.2 Circular Vial	112
15.3 Compensator	112
15.4 Inclination of Reticle	114
15.5 Perpendicularity of Line of Sight to Horizontal Axis (2	2c)115
15.6 Adjustment of Vertical Index Difference and Vertical	Angle 0
Datum	116
15.7 Optical Plummet	117
15.8 Laser Plummet	118
15.9 Instrument Constant (K)	119
15.10 Parallel between Line of Sight and Emitting Photoe	lectric
Axis	121
15.11 Tribrach Leveling Screw	121
15.12 Related Parts for Reflector	122

16.SPECIFICATION	123
17. ERROR DISPLAYS	126
18. SAFETY INSTRUCTIONS	126
18.1 Integrated EDM (Visible Laser)	1 <u>25</u>
18.2 Laser Plummet	1 <u>28</u>

1. FEATURES

1. Abundant Functions

This series of total station have different kinds of measurement programs and many strong functions such as data storage and parameter setting, suitable for all kinds of engineering measurement and professional requests.

2. Colorful Touch Screen

This series of total station use 3.0 inches colorful touch screen, which can enrich the display and simplify the operation.

3. SD Card Support

Supporting 32G SD memory card in maximum, and the data can be exported to the SD card in any time.

4. Automatic Data Collection

Automated field data collecting program, can record measurement data and coordinate data automatically, N3 can also transfer data to PC directly, realize the real digital survey.

5. Lighter Telescope Lens

The total station of new generation have more scientific and reasonable design in appearance and internal structure, the smaller telescope makes the measurement more convenient.

2. PREPARATION

2.1 Precautions

1). Please do not aim at the sun. If you need to do the outside working under sunshine, please use a filer.

2). Please do not store the instrument in extreme temperatures and also avoid sudden change.

3). When not using the instrument, please place it in the case to avoid shock, dust, and humidity.

- 4). If there is a great difference in temperature between the working place and storage location, leaving the instrument in the case until it adjust the surrounding temperature.
- Please remove the battery for separate storage if do not use the instrument for a long time.
 The battery should be charged once a month.
- 6). The instrument should be placed in its carrying case during transportation. It is recommended that the original packing case should be used for cushioning during extended transportation.
- 7). Please hold the instrument in one hand when mounting or removing it from the tripod.
- 8). Please cleaning the optical parts with cotton or lens tissue only.
- 9). Please clean the dust with a woolen cloth when finished to use it. If the instrument get wet, please power off then cleaning the surface and also waiting for drying.
- 10).Check the battery, functions, and indications of the instrument as well as its initial setting and correction parameters before operating.
- 11). Please do not disassemble the instrument without authorize to escape the damage.
- 12). DO NOT stare into the beam or laser source when instrument is operated.

2.2 Appearance





2.3 Unpacking and Storage of the Instrument

Unpacking of the Instrument

Place the case lightly with the cover upward, unlock the case and take out the instrument.

Storage of the Instrument

Replace the cover on the telescope lens, place the instrument into the case with the vertical clamp screw and circular vial upward (objective lens toward the tribrach), tighten the vertical clamp screw, close and lock the case.

2.4 Instrument Set Up

Mount the instrument onto the tripod and secure firmly. Level and center the instrument precisely to ensure the best performance. Use the tripod with a tripod screw.

Operation Reference: Leveling and Centering the Instrument

1). Setting up the tripod

First extend the extension legs to suitable length and tighten the screws, firmly plant the tripod in the ground over the point of beginning.

2). Attaching the instrument to the tripod

Secure the instrument carefully on the tripod and slide the instrument by loosening the tripod mounting screw. If the optical plumb site is positioned over the center of the point tighten the mounting screw.

3). Roughly leveling the instrument by using the circular vial

Turn the leveling screw A and B to move the bubble in the circular vial, in which case the bubble is located on a line perpendicular to a line running through the centers of the two leveling screw being adjusted. Turn the leveling screw C to move the bubble to the center of the circular vial. Recheck the position of the instrument over the point and adjust if needed.

4). Leveling by using the plate vial

Rotate the instrument horizontally by loosening the Horizontal Clamp Screw and place the

5

plate vial parallel with the line connecting leveling screw A and B, then bring the bubble to the center of the plate vial by turning the leveling screws A and B.

Rotate the instrument 90° (100gon) around its vertical axis and turn the remaining leveling screw or leveling C to center the bubble once more.

Repeat the before procedures for each 90° (100gon) rotation of the instrument and check whether the bubble is correctly centered in all directions.

5). Centering by using the optical plummet(or laser plummet)

Adjust the eyepiece of the optical plummet telescope to your eyesight. Slide the instrument by loosening the tripod screw; place the point on the center mark of the optical plummet. Sliding the instrument carefully as to not rotate the axis will allow you to get the least dislocation of the bubble. (Press \bigstar after power on, then press [\blacktriangleright] (LASER) key to turn on the laser plummet.Slide the instrument by loosening the tripod screw; Place laser facular on the occupied point, sliding the instrument carefully as to not rotate the axis will allow you to get the least the least dislocation of the bubble. The last, press [\blacktriangleright] key, and laser plummet will be turned off.)

6). Complete leveling the instrument

Level the instrument precisely as in Step 4. Rotate the instrument and check to see that the bubble is in the center of the plate level regardless of the telescope direction then tighten the tripod screw firmly.

Press ★ key, then press 2 key to enter the E bubble page.



2.5 Battery Removal & Insertion – Information and Recharging

Insert the battery into the battery slot and push the battery until it clicks.

Press the right and left buttons of the battery compartment to remove the battery.

Battery information

Please stop the operation when battery is in low voltage, and change a recharged battery for operation.

Note:

 The working time of the battery is determined by environment conditions, such as: surrounding temperature, recharging time and recharging frequency. For safety, recharge the battery in advance or prepare a recharged battery for use.

2) The display level of leftover battery capacity is related to current measurement model, even the leftover battery is enough to in angle measurement mode, but you cannot make sure it is enough to use in distance measurement mode. Because the power consumption of distance measurement model is higher than angle measurement model, when turn the angle measurement model to distance measurement model, sometimes it may stop measure distance and the instrument shut down because of insufficient capacity of battery.

Battery Recharging :

Battery should be recharged only with the specified charger.

The charger should be connected with 220V power supply first when recharging ,then remove the battery from instrument ,put the plug of the charger into the socket.

Battery Removal Caution

▲ Before you take the battery out of the instrument, make sure that the power is turned off. Otherwise the instrument would be damaged.

7

Recharging Caution

▲ The charger has built-in protection circuit from overcharging. However, do not leave the charger plugged into the power outlet after recharging is completed.

▲ Be sure to recharge the battery at a temperature of $0^{\circ}C^{\sim}45^{\circ}C$, recharging may be abnormal beyond the specified temperature range.

▲ When the indicator lamp does not light after connecting the battery and charger the battery or the charger may be damaged.

Storage Caution

▲ Complete discharge of battery may shorten its service life.

▲ In order to get the maximum service life be sure to recharge the battery at least once a month.

2.6 Assemble and Disassemble the Tribrach

Disassemble

If necessary, you can disassemble the tribrach from N3. Loosen the tribrach locking screw in the locking knob by a screwdriver. Turn the locking knob 180 degrees counter-clockwise to disengage anchor jaws and remove the instrument from the tribrach.



Assemble

Insert three anchor jaws into holes and line up the directing stub on the instrument with the directing slot of the tribrach. Turn the locking knob 180 degrees clockwise and tighten the locking screw by a screwdriver

2.7 Eyepiece Adjustment and Object Sighting

Method of Object Sighting (for reference)

1) Sight the telescope to the sky and rotate the eyepiece tube to make the reticle clear.

 Collimate the target point with top of the triangle mark in the collimator.(keep a certain distance between eye and the collimator).

3) Make the target image clear with the telescope focusing screw.

If there is parallax when your eye moves up and down or left and right this indicates the diopter of the eyepiece lens or focus is not adjusted well and accuracy will be effected. You should readjust the eyepiece tube carefully to eliminate the parallax.

2.8 Power On & Off

Power on

1) Be sure that the instrument is leveled.

2) Press and momentarily hold the power (POWER) key.

3) Rotate the EDM head in an upwards direction to initialize.

4) To turn OFF press and hold the power key until instrument powers down

Be sure about there is sufficient battery power when operating. If 'Low Battery' is shown on the display, the battery should be recharged or replaced.

*** DO NOT remove the battery during measuring, otherwise the data will be lost and the instrument would be harmed!!***

2.9How to Enter Alphanumeric Characters

This Chapter is introducing how to input the alphanumeric characters, such as Instrument height, Prism height, station points and BS point etc, selecting * item and input of numbers.

[Example 1] Select I.HT (instrument height) in the data Set Stn (first press the MENU button then 5: Set Stn and then press F4,. Press 1(Known Pt), then get into the setting page.

The arrow (\rightarrow) indicates an item to enter. Press [\blacktriangle] [\triangledown] key to move the arrow line up or down

	S1	tn Pt	123	→ 🗟 🛅 💳
	Pt	N		
	Co	de 🗌		
	Inst.	Ht 0.00	0	m
	Input	New	Call	Next
Press [▼] move →I.H	т			
	Stn	Pt	123 →	🗟 🛲
	Pt N			
	Code			
	Inst.Ht	0.000		m
	Input	New	Call	Next
Press 1 to input "1"				
Press . to input "."				
Press 5 to input "." Press 5 to input "5"				
Press 1 to input "1" Press 5 to input "." Press 5 to input "5" Then I. HT =1.5 m				
Press : to input "." Press 5 to input "5" Then I. HT =1.5 m	Str	ı Pt	123 - 1	i B. 🛅 💳
Press 1 to input "1" Press 5 to input "5" Then I. HT =1.5 m	<u>Str</u> Pt 1	ı Pt	123 →	8 🛅 🛲
Press 1 to input "1" Press 5 to input "5" Then I. HT =1.5 m	<mark>Str</mark> Pt 1 Cod	1 Pt N	<u> 123 →</u>	<mark>↓ 8. ⊞ ●</mark>
Press 1 to input "1" Press 5 to input "5" Then I. HT =1.5 m	Str Pt 1 Code Inst.H	1 Pt	123 →	<mark>∮ 8. ⊞ ==</mark>

*How to enter characters

[Example 2] Input the code "ABCDE" for measuring point in Set Stn Mode Known Pt.

1.Press $[\Psi]$ or $[\blacktriangle]$ key to move the arrow,when move to the inputting item, press the switch key α

Stn Pt	123 🚽 🗟 🛗 🛲
Pt N	
Code	
Inst.Ht 1.5	Ш
	Next

- 2. Press [7] key once for "A"
- Press[7] key twice for "B"
- Press [7] key three times for "C"
- Press [8] key once for "D"
- Press [8] key twice for "E"

Press enter key to finish input

Stn Pt	ABC \rightarrow	8 🖩 🖛
Pt N		
Code ABCDI	3	
Inst.Ht 1.5		Ш
	Ca11	Next

3. FUNCTION KEY AND DISPLAY

3.1 Operating Key



Keys	Names ·	Function
\swarrow	Angle meas.	Angle measurement mode
	Distance meas.	Distance measurement mode
	Coordinate meas.	Coordinate measurement mode
\langle	Backspace	Delete characters before cursor
	Direction key	[▲] Up [▼] Down
◀ ►	Direction key	[◀]Left [▶]Right
ESC	Escape	Return to the measurement mode or previous page
ENT	Enter	Inputting values or OK.
MENU	Menu	Switches menu mode and normal mode
α	Conversion key	Switch character and number
\star	Star key	Quick setting
Ċ	Power key	On/Off key press and hold
F1—F4	Function key	Responds to the message displayed
0—9	Number key	Input numbers and letters
—	Minus key	Input minus ,plus ,multiply ,division sign
	Point key	Input point character

Display marks:

Display	Content
V%	Vertical angle as a percentage (Gradient display)
R/L	Horizontal angle (right/left)
PPM	Atmospheric correction

3.2 Function Key

Angle measurement mode

	Ang l	Meas.	→	🗟 🛅 💳
	VA 276		° 22′ 05	"
HL 54°31′00″				"
C) set	Lock	Hset	1/2
) set V%	Lock R/L	Hset VA	1/2 2/2
C) set V%	Lock R/L	Hset VA	1/2 2/2 ↓

Page	Soft keys	Display marks	Function
	F1	OSET	Horizontal angle is set to 0°0′0″
1/2	F2	HOLD	Hold the horizontal angle
	F3	HSET	Set a required horizontal by entering numbers
	F4	1/2	Scroll to the next page(P2)
	F1	٧%	Vertical angle percent grade(%) mode
2/2	F2	R/L	Switches Right/Left rotation of horizontal angle
	F3	Vertical Angle	Switch vertical angle and zenith distance
	F4	2/2	Scroll to the first page

Distance measurement mode

Dist.	→ 🗟 🛅 🛲		
v	A 276	° 22′	05″
Н	A 54	° 31′	03″
S	D		m
Н	D		m
V	D		ш
Meas.	Mode	S0	
\downarrow	\downarrow	\downarrow	\downarrow
F1	F2	FE	3 F4

Page	Keys	Display	Function	
	F1	MEAS	Begin measuring	
1/1 F2 MODE Sets measuring mode, Fine//Tracking F3 SO. Select Stake Out measurement mode		Sets measuring mode, Fine//Tracking		
		Select Stake Out measurement mode		

Coordinate measurement mode

Coord	. M	leas.			→	8 🖫 🖛	
V.	A	284	0	54'	06″	•	-
н	A	43	0	52'	55″	,	
1	N					m	
1	E					m	
	Z					m	
Meas.		Mode		Stn		1/2	
R. HT		I.HT		В	S	2/2	
\checkmark		\downarrow		\downarrow		\downarrow	
F1		F2		F	3	F4	

Page	Keys	Display marks	Function	
	F1	MEAS	Start measuring	
1/2	F2	MODE	Sets a measuring mode, Fine/Tracking	
F3 STN Sets instrume		STN	Sets instrument coordinate	
	F4	1/2	Shows the function of soft keys on page 2	
	F1	R.HT	Sets prism height	
2/2	2/2 F2 I.HT Sets instrument height		Sets instrument height	
F3 BS Setting coordinate for back sight o		Setting coordinate for back sight orientation		
	F4	2/2	Shows the function of soft keys on page 1	

3.3 Star-key

Press the star key, following is displayed:

Quick settings	SD 🖛		
1.Target	2.E bubble		
3.PPM setting	4. Meas. mode		
5.EDM Laser	6. Power		
7.Plummet			
Back	Time Info		

1. Press cooperation mode, shown as below:

Targe	t mode		💼 🛲
Targe	t Prism	 	
PSM-	C -30		
Back			OK

Three cooperation target could choose: Non-prism, Prism and Sheet, choose one mode then press [OK] return the last page.

Note: In the prism mode, you can change the prism constant, as the default setting is "-30".

2. E bubble: electronic bubble can be adjust in this page..

3. Press PPM Setting to enter meteorology value setting page. If TP auto show "close", then you should measure the surrounding temperature and pressure of station point, and input the values. If it show "open", it will show the Temperature and Press value measured by the T&P sensor.

If it shows "close", for example: Temperature: 20° C, Pressure: 1017hPa, it will shown as following page:

T&P cor	rection	123	💼 🛲
Т.	20.0		
Р.	1017		hPa
PP	1 276.4		
TP auto	o Close		•
Back			OK

4. Meas mode: Press [◀] or [▶] to switch Fine, Repeat and tracking measurement, press "OK" to confirm.

Note: You can choose the measurement times in Fine measurement mode, as following image:

Mode s	etting		💼 🛲
Mod	e Fine		
Times 2 times			
Back			OK

- 5. EDM Laser: On or off the EDM laser pointer
- 6. Power : Setting for Battery management, Back-light setting, Cross-hair back-light
- 7. Laser plummet(Only for TS with Laser plummet): Control the on/off and

luminescent of Laser plummet, choose [OK] to finish, as following image:

Laser j	pointing	💼 🖛
Statu	s Close	
Inst.H	t 1.500	m
Meas.		OK

4. INITIAL SETTINGS

4.1 Setting the Temperature and Atmospheric Pressure

If the T&P correction of the Total Station is closed, you should follow the steps below; If it is opened, there is no need to set the Temperature and Atmospheric Pressure, the instrument will detect the Temperature and Atmospheric Pressure automatically, and make the correction with PPM.

Measure the temperature and air pressure of the station point in advance. For example: Temperature +25 $^\circ\!C$, Air pressure 1017.5hPa.

Procedure	Operation	Display	
①Press star key to enter quick settings	*	Quick settings 1. Target 2. E bubb 3. PPM setting 4. Meas. me 5. EDM Laser 6. Power 7. Plummet Time	
(2) Enter PPM setting. Measure the temperature and air pressure of the station point in advance	З	T&P correction 123 T. 20.0 P. 1017 PPM -1.0 TP auto Close Back	
③Press [▲]or[▼] to temperature setting	[▲]or[▼]	T&P correction 123 T. 20.0 P. 1017 PPM 276.4 TP auto Close Back	□ hPa □ hVa □ hVa □ 0K

④Input temperature, press OK to		T&P correction 12	3 🛄 🛲		
confirm. The same setting for Air pressure. The instrument will calculate atmospheric correction value automatically	Input temperature *1)	T. 25 P. 1017.5 PPM 3.5 TP auto Close Back	hPa ▲ ▶ 0K		
Remarks:					
*1) Please refer to 2.10 "How to Enter Alphanumeric Characters"					

Temperature operating range: -30° +60 °C (interval 0.1 °C) or -22° +140 °F (interval 0.1 °F)

Air pressure range: 560~1066hPa (interval 0.1hPa) or 420~800mmHg (interval 0.1mmHg) or

16.5~31.5inHg (interval 0.1inHg)

The setting of Air pressure is same as temperature setting

If the atmospheric correction value calculated from the temperature and air pressure exceeds

the range of $\pm 999.9 \times 10^{-6}$ PPM, the operation will return to step 4 automatically, and you

should enter the data again

4.2 Setting of the Atmospheric Correction

The infrared emitted by the Total Station varies with the air temperature and pressure.

Once the atmospheric correction value is set ,the instrument will correct the distance

measuring result automatically.

Air pressure: 1013hPaTemperature: $20^{\circ}C$ The calculation of atmospheric correction : $\Delta S = 273.8 - 0.2900 P / (1 + 0.00366T) (ppm)$ ΔS : Correction Coefficient (Unit ppm) P: Air Pressure (Unit : hPa If the unit is mmHg , please convert using

1hPa = 0.75mmHg 1mmHg = 1.333hPa

T: temperature ($unit^{\circ}C$)

Direct Setting Method of Atmosphere Correction Value

Operation Procedure	Operation	Display			
①Press star key into quick setting, then press ᢃ	3	T&P correction 123 Image: Constraint of the second se			
②Press [▲] or [▼] to PPM	[▲]or[▼]	T&P correction 123 Image: Constraint of the second se			
③Input data and press [OK]	Input data	T&P correction 123 Image: Correction T. 25 P. P. 1017.5 hPa PPM 3.5 TP auto Close Back OK			
*1) Refer to 2.10"How to Enter Alphanumeric Characters"					
Input range: -99. 9PPM to +99. 9 Interval: 0 .1PPM					
*2) If Temperature and Air Pressure are reset, the PPM will be recalculated automatically.					

After measuring the temperature and air pressure, the atmosphere correction value can be obtained from an atmospheric correction chart or correction formula (PPM).

4.3 Setting of the Prism Constant

The default setting of prism constant for the total station is -30mm. If the constant of the prism is not -30mm, you must change this setting. Once the prism constant is set ,it will become the new default value until changed.

Operation Procedure	Operation	Disp	blay	
① Press star key into quick setting	Press ★ key	Quick settings 1. Target 3. PPM setting 5. EDM Laser 7. Plummet Back	2.E bubble 4.Meas.mode 6.Power Time Info	
② Press 1 key to choose Target	а	Target mode Target Prism PSM-C -30 Back	■ ●	
③Input prism constant correction *1), press ENT	Input data	Target mode Target Prism PSM-C -30 Back	■	
*1) Refer to 2.10 "How to Enter Character" Input range: -99.9mm to +99.9mm Step length 0.1mm				

*The total station in reflectorless measuring mode sets the prism constant to 0 automatically.

5. ANGLE MEASUREMENT

5.1 Measuring Horizontal Angle Right and Vertical Angles

Make sure the angle measurement mode is selected

Operation Procedure	Operation	Display
		Ang Meas. 🚽 🗟 🖽 🛲
\bigcirc Aim at the first target (A)	Λim Target Δ	VA 262°44′17″
	Allin laiget A	HL 135°40′09″
		0 set Lock Hset 1/2
		0 set → 🗟 🖫 🛲
		Set HA to 0°?
②To set horizontal angle of	F1	
target A at 0°0'0". Then press		Cancel OK
theF1 (0SET) key and then press		Ang Meas. → 🖲 🛅 🖛
the <mark>F4</mark> (OK) key	F4	VA 262°44′17″
		HL 0° 00′ 00″
		0 set Lock Hset 1/2
		Ang Meas. 🚽 🗟 🖽 🛲
③Aim at the second target (B).		VA 262°36′15″
The required V/H angle to target	Aim Target B	
B will be displayed		HL 179°38′07″
		0 set Lock Hset 1/2

Note : The horizontal angle will be saved when the instrument is powered off and displayed when powered on.

Reference: How to Aim at the Target

①Point the telescope toward a light surface or sky. Rotate the eyepiece ring and adjust the focus so that the cross hairs are clear in your view.

②Aim the target by the peak of triangle mark on the EDM. Allow a certain space between the sighting collimator and yourself.

(3) Adjust the optical lens to clear the target.

If parallax is occur between the cross hairs and the target when viewing vertically or horizontally while looking into the telescope, focusing is incorrect or eyepiece adjustment is poor. This adversely effects precision in measurement. Please eliminate the parallax by carefully focusing and adjust the eyepiece before working.

5.2 Switching Horizontal Angle (Right/Left)

Make sure the angle measurement mode is selected

Operation procedure	Operation	Display
①PressF4 (1/2) key to get the menu to page 2.(P2)	F4	Ang Meas. → Image: Im
②Press the F2(R/L) key. The Horizontal Right angle mode (HR) Switches to Horizontal Left mode(HL)	F2	Ang Meas. → S □ VA 270° 50′ 19″ HR 6° 10′ 39″ V% R/L VA 2/2

③Measurement same as HL			
mode			
*Each time the F2 (R/L) key is pressed the HR/HL mode switches			

5.3 Setting of the Horizontal Angle

5.3.1 Setting by Holding the Angle

Make sure the angle measurement mode is selected

Operation procedure	Operation	Display
 Set the required horizontal angle using the horizontal tangent screw 	Display angle	Ang Meas. → Image: Image isotropy VA 270° 50′ 19″ HL 354° 19′ 52″ 0 set Lock Hset 1/2
② Press the F2 (LOCK) key	F2	Lock → 8 m ← HA Lock! 354°19′52″ Back 0K
③Aim the target	Aim	
④ Press the F4 (OK) key to finish holding the horizontal angle*, the display turns back to the angle measurement interface	F4	Ang Meas. → Image: Image i

5.3.2 Setting the Horizontal Angle by Manual

Make sure the angle measurement mode is selected.

Operation procedure	Operation	Display
①Aim the target	Aim	Ang Meas. → ● ● ● VA 276° 22′ 05″ HL 54° 31′ 00″ 0 set Lock Hset 1/2
②Press the F3 (HSET) key	F3	HSet 123 → 8 🖼 🖛 HA 🛛 Back 0K
③Input the required horizontal angle by using the keys*, for example : 150.10.20, inputs 150°10'20". Press ENT Carry on normal measurement after entering the required horizontal angle	Eg. Input 150.1020 F4 ENT	HSet 123 → S Image: Control = 1 HA 150.1020 0K Back 0K 0K Ang Meas. → S Image: Control = 1 VA 276° 18′ 45″ HL 150° 10′ 19″ 0 set Lock Hset 1/2

5.4 Vertical Angle Percent Grade (%) Mode

Make sure the angle measurement mode is selected.



5.5 Setting the Initial Zenith Angle

Vertical angle is displayed as shown below:

Zenith (00° 00' 00")



Zenith (00° 00' 00")



Make sure the angle measurement mode is selected.



6.DISTANCE MEASUREMENT

Before distance measurement, it usually need to confirm the setting of atmospheric correction and prism constant. It is necessary to check I angle of the instrument at first. Please refer to the setting steps of V0 ADJUSTMENT(I angle)

N3 series have three kinds of measuring mode in distance measurement: 1)Prism, need to aim at the target prism. 2).Sheet, need to aim at the target sheet. 3).Non-Prism, only need to aim at the target subject.

6.1 Setting the Atmospheric Correction

The atmospheric correction can be settled to the correction value by measuring the temperature and pressure. Refer to section 4.2 "Setting of the Atmospheric Correction".

6.2 Setting the Prism Constant

The default value of prism constant is -30mm. If you need to choose the other prism for measurement, please setting the correct prism constant before working. Refer to Chapter 4.3 "Setting of the Prism Constant". The updated value is kept in the instrument even after power off.

6.3 Distance Measurement (Continuous Measurement)

In angle measurement mode:

Operation procedure	Operation		D	isplay						
	Aim	Ang	Meas.	-	8 🖩 🖛					
①Aim at the center of prism		v	A 276	6°22′0	5″					
							Н	R 305	5° 29′ 00	D″
		V%	R/L	VA	2/2					

②Press the key, distance measurement starts *1)-*4)		Dist. Meas. → Image: Control = 1 VA 276° 22′ 05″ HA 54° 31′ 03″ SD m m HD m m VD m Meas. Mode SO		
*1)If you want to set automatic distance measurement after power on, please refer to the				
steps in Chapter 14 "Setting".				
*2)The unit of distance is "m" (meter) in default ,the distance data will be updated after each				
measurement finished along with the beep.				
*3)If the measurement result is	affected by	the atmospheric agitation, the instrument can		

repeat the measurement automatically.

*4)If you want to return to the angle measurement mode from the distance measurement mode, pls press ANG key.

6.4 Changing the Distance Measurement Mode(Repeat Measurement / Single Measurement/ Track Measurement)

Operation procedure	Operation	Display
①Aim at the center of the prism	Aim	<u>Ang Meas.</u> → 🗟 🛅 🖛 VA 276°22′05″ HL 54°31′00″
		0 set Lock Hset 1/2

②Press key*1)		Dist. Meas. → Image: Control in the system VA 276° 22′ 05″ HA 54° 31′ 03″ SD m HD m VD m Meas. Mode SO
③Press F2 to enter, then press [◀]or[►] to switch between fine mode, repeat mode and tracking mode	F2,then press[◀]or [▶]	Mode setting Mode Fine Times 2 times Times 2 times Back OK Mode setting Mode Repeat Back Mode setting Mode Setting Mode Setting
*1)You can set the measuring m	ode when N3 is	power on

In angle measurement mode:

6.5 Stake Out(S.O.)

This function can show the difference between measured distance and the input stake out distance; Measured distance - Stake out distance = Displayed value

In a stake out operation you can select either horizontal distance (HD), relative elevation (VD), and slope distance (SD.)

Operation procedure	Operation	Display
①In the distance measuring mode		Dist. Meas. → ⑧ ■ VA 276° 22′ 05″ HA 54° 31′ 03″ SD m m HD m VD Weas. Mode SO
② Press $F3(S.O)$ key, the data previously set is shown	F3	Dist.S0 123 → 🗟 🖾 🖛 SD 10.000 m SD HD VD 0K
③Select the measuring mode by pressing the F1toF3keys. F1: SD, F2: HD, F3: VD eg: HD	F1	Dist. S0 123 → ③ □□ HD 0.000 m SD HD VD 0K
④Input S.O. distance, press ENT	Input 1.5 ENT	Dist.SO 123 → 8 🕮 🖛 HD 1.5 m SD HD VD OK
---	------------------	---
(5) Aim at the target (Prism), and start measurement. The difference between the measured distance and the stake out distance is displayed.	Aim the Prism	Dist. S0 → § ■ VA 276° 22′ 05″ HA 54° 31′ 01″ HD 0.184 m HDD -1.316 m Meas. Mode S0
6 Move the target until the value becomes 0	viteb to other	Dist. S0 → Image: Control = 0 VA 276° 23′ 51″ HA 341° 55′ 52″ HD 0.728 m HDD -0.772 m Meas. Mode S0
value becomes 0 If the value come to zero or sv	witch to other 1	HDD -0.772 m Meas. Mode S0 measurement mode, N3 will back to normal

distance measurement surface.

7.COORDINATE MEASUREMENT

By entering the coordinate of station point, instrument height ,prism height and the azimuth of Back-sight point, 3D coordinate of Measuring Point can be measured automatically.

7.1 Procedures of Coordinate Measurement

Measure the coordinates by entering the instrument height and prism height, coordinates of unknown Point will be measured directly.

* Please setting coordinate values of occupied point refer to Section 7.2 "Setting Coordinate Values of Occupied Station Point".

* Please setting the instrument height and prism height, refer to Section 7.3 "Setting Height of the Instrument" and 7.4 "Setting Height of Target (prism Height)".

* Back-sight point is needed and then find the back-sight azimuth before the normal coordinate measurement.

The coordinates of the unknown point are calculated as shown below:

Coordinates at occupied point : (N0 , E0 , Z0)

Coordinates at the center of prism, originated from the center point of the instrument :(n ,

e , z)

Instrument height :INS.HT	Coordinates of unknown point : (N1 , E1 , Z1)
Prism height: R.HT	Vertical distance (Relative elevation): Z (VD)
N1=N0+n	
E1=E0+e	
Z1=Z0+INS.HT+Z - R.HT	
Center point of the instrument (N	0, E0, Z0+Inst.Ht)



When doing coordinate measurement, you need to set coordinates of occupied point, the instrument height, the prism height and back-sight azimuth at first.

Operation procedure	Operation	Display
		Ang Meas. 🚽 🗟 🖽 🛲
	Set direction	VA 276°22′05″
1Set the direction angle of	angle	
known point A *1)		HL 54°31′00″
		0 set Lock Hset 1/2
(2) Aim at target prism B, and	Aim at target	Dist.Meas. 🚽 🗟 🕮 💳
		VA 276°22′05″
press key	prism	HA 54°31′03″
		SD m
		HD m
		VD m
		Meas. Mode SO

*1)Refer to Section 5.3 "Setting of Horizontal Angle".

In the condition of lacking the coordinate of station point, (0,0,0) or the coordinate you input

last time, will be used as the default station point.

The prism height will be 0 if the prism height hasn't been set.

7.2 Setting Coordinate Values of Station Point

Set the coordinates of the instrument (Station point) refer to the origin points in coordinates, then N3 can automatically converts and displays the unknown point (prism point) coordinates into this exist coordinate system.

The instrument will keep the data of station point after power off.



Operation procedure	Operation	Display
①In coordinate measurement mode	\square	Coord. Meas. → Image: Coord. Meas. VA 284° 54′ 06″ HA 41° 26′ 24″ N m E m Z m Meas. Mode Stn
②Press F3(Stn)key	F3	Input Stn 123 → S Im N 0.000 m E 0.000 m Z 0.000 m Back OK



7.3 Setting Height of the Instrument

The instrument height value will be retained after power off.

Operation procedure	Operation	Display
		Coord. Meas. → 🗟 🖫 🛲
		VA 284° 54′ 06″
① Press the <u>F4</u> (1/2) in the		HA 43° 52′ 55″ 💻
coordinate measurement	F4	N m
mode to access the P2 many		E m
mode to access the P2 menu		Z m
screen.		Meas. Mode Stn 1/2
		K.HI I.HI BS Z/Z

②Press the F2 (I.HT). The value will show the current Inst.Ht.	F2	Inst.Ht 123 → 🗟 🛅 🖛 Inst.Ht 0.000 m
③Enter the instrument height and press the ENT key to back to the coordinate measuring function.	Enter the I.H. ENT	Coord. Meas. → B ■ VA 284° 54′ 06″ HA 42° 29′ 09″ N m E m Z m R.HT I.HT BS 2/2

7.4 Setting Height of Target (Prism Height)

This mode can be used to calculate z coordinate values. The target height value will be saved after power off.

Operation procedure	Operation	Display
① In coordinate measurement mode, press F4 (1/2) to enter P2	F4	Coord. Meas. → Image: Coord. Meas. VA 284° 54′ 06″ Image: Coord. Meas. HA 43° 52′ 55″ Image: Coord. Meas. N Image: Coord. Meas. Image: Coord. Meas. Z Image: Coord. Meas. Image: Coord. Meas. Meas. Mode Stn 1/2 R. HT I. HT BS 2/2

② Press F1 R.HT to display the current prism height	F1	Coord. Meas. → Image: Coord. Meas. VA 284° 54′ 06″ HA 42° 29′ 09″ N m E m Z m R.HT I.HT BS 2/2
		R. HT 123 → 🗟 🖽 🛲
3 Input the prism height and	Enter the	
press ENT to confirm and back	R.HT.	R. HT 0.000 m
to coordinate measuring	ENT	
function		Back OK

8.DATA COLLECTION

Data collect menu operation



8.1 Point Collect

Point Collect has two different modes (1): Measure first (2) Input first. The difference between two modes is input point name and code at first or not.

Choose "Auto" when automatic save is needed. Otherwise, choose "Manual".

Coordinate measurement, angle measurement and distance measurement can be switched anytime when measuring.

Take [Input first] mode as an example, other measurement operation are similar. Press α to switch the alphabet to numbers when input point name.

Operation procedure	Operation	Display
①Press扣(Pt collect) from collect menu.	1	Collect → Image: Sector Sect
②Collect setting choose "Input", automatic save choose "Auto".	press[◀]or[▶]to switch	Setting → 🕅 🖿 Collect Input ← ► Save Auto ← ► Back Next
③Press F4 (next) into input point page	F4(next)	Pt N 123 → S Immedia Pt N

 ④ Input Point name and code first, then press[◀]or[►] to switch Eg: Distance 	F3	Pt N ABC → S Imm Pt N DATE_1 Code Code <t< th=""></t<>
5 Aim at target point	Aim	
⑥ Press F4 to measure and save automatically	F4	Coord. Meas. → B ■ VA 284° 54′ 06″ HA 41° 26′ 24″ N m E m Z m Meas. Mode Stn 1/2
⑦Input the next point name and code, aim at the target		Pt N ABC→ ③ Pt N DATE_2 Code EFGH R.HT 0.000 m Mode Dist. ↓ Back Call List Meas.
⑧Repeat steps from ④to⑥		



④Press F1key (Measure)	F1	Coord. Meas. 123 → Im R. HT 0.000 m N 12.619 m E 1.794 m Z 9.081 m Meas. Back OK
⑤Press F2key (Coordinate) to get the coordinate of offset point	F2	Coord. → S Imm N 14.822 m E 1.088 m Z 12.077 m Back
[®] PressF4 (Next) in step (4), record the measurement data, then measuring the next point	F4	Save ABC → E Im Pt N DATE_3 Code [ABCD] Back Call OK

8.3 Plane Offset Measurement

This function is used for the point cannot be measured directly, such as the distance or coordinate of the points on border.

Three random prism points (P1, P2, P3) on a plane should be measured at first in the plane-offset measurement mode, to determine a measured plane. Aim at the measuring target point (P0) then the instrument will calculate and display coordinate and distance values of the cross point between collimation axis and this plane; also you can input coordinate or call the coordinate file to take measurement

P1	I,P2,P3 are three ra	indom prism points
Target Point P0		The prism height value of P1,P2,P3 is automatically set to be 0
Operation procedure	Operation	Display
 Press Bkey from collect mode to enter Plane Offset Measurement. Then choose F1/F2/F3 for measurement, call or input coordinates. 	3 F1	Plane Corner Pt 123 → 🗟 🛅 🖛 Pt1 Pt2 Pt3 Meas. Call Input Next
② Aim at prism point 1, press F1 (Meas.) key	Aim point1 F1	Coord. Meas. 123 → E Im R. HT 0.000 m N 13.738 m E 3.051 m Z 9.111 m Meas. Back OK
③ PressF4 (OK) key	F4	Plane Corner Pt 123 → Image: Constraint of the second secon

④ The second and third point should be measured in same way	Aim point2 F1 Aim point3 F1	Coord. Meas. 123 → [§] [□] R. HT 0.000 m N m E m Z m Meas. Back 0K Coord. Meas. 123 → [§] [□] R. HT 0.000 m N 4.179 m E -1.099 m Z 1.621 m Meas. Back 0K
 Fress F4 (Next) key Aim at the target point on the plane, the display will show horizontal and vertical angle of the point*1) *2) 	F4	Plane Corner Pt 123 → S Image: Corner Pt Pt1 @Meas. Pt2 @Meas. Pt3 Pt3 @Meas. Pt3 Image: Corner Pt 123 → S Image: Corner Pt Meas. Call Input Next Plane corner Pt 123 → S Image: Corner Pt 123 → S Image: Corner Pt R. HT O.000 Image: Corner Pt 123 → S Image: Corner Pt 123 → S Image: Corner Pt VA 290° 33' 52″ HA 200° 51' 33″ Image: Corner Pt 123 → Image: Corner Pt
\widehat{T} Press F2(Distance), SD, HD and VD of the point will be shown on the display	F2	Dist. Cold. Save Dist. → Image: Cold. Save VA 241° 42′ 08″ HA 50° 35′ 29″ SD 2.091 m HD 0.991 m VD 1.841 m Back

		Coord. 🚽 🖲 🖽 🚥
8 PressF3 (Coordinate) key,		N 9.371 m
show the coordinate of the	F3	E 5.766 m
target point		Z 9.341 m
		Back
		Save 123 → 🗟 🛅 🛲
		Pt N
9 Press F4 (ok) key to save	E4	Code
the measured data	Г4	
		Back OK
		Save ABC -> 🗟 🛅 🖛
		Pt N DATE_1
		Code ABCD
1 Input point name and		
code(Code also can be called by		Back Call OK
Drees [2] from Code data	53	$\frac{\text{Code data}}{1} \rightarrow \boxed{\textcircled{1}} = 1$
Press F3 from Code data	F3	$\frac{1}{2} \qquad \text{ABCDE} \qquad \leftarrow$
		-
		Doloto Nom Rind Edit
		Delete New Find Edit
*1) If three measured point ca	nnot define a p	lane by calculation, the display will show no

intersection ,then the measurement should start from the $\mathbf{1}^{\text{st}}$ point again.

*2) No intersection will be displayed when target point and defined plane have no intersection.

8.4 Column Offset Measurement

Measuring circumscription point (P1) on column at first, then the distance to the center of the column (P0) can be calculated by measured direction angle of circumscription points (P2) and (P3).

The angle of center point is equals to the average value of direction angle about P2 and P3.



Operation procedure	Operation	Display
①Press 4 from collect mode to enter Plane Offset Measurement		Column center Pt 123 → 🗟 🛅 🚥 R.HT (0.000) m HD m Pls measure column center HD
		Meas. Next Column center Pt 123→ 🗟 🗒 🚥
② PressF1 (Measurement)	F1	R.HT [0.000] m HD m
		Pls measure column center HD Meas. Next

③PressF4 (Next)	F4 Aim at the left direction	Column center Pt 123 → S Im R.HT Im Im Im HD 0.961 Im Left 50° 35′ 28″ Meas. left azimuth Next
④Press F4(Next)	F4 Aim at the right direction	Column center Pt 123 → Image: Column center Pt 123 → Image: Column center Pt R. HT O. 000 m HD 0.961 m Left 50° 35′ 26″ Right 34° 57′ 28″ Meas. right azimuth Cal.
⑤PressF4 (Cal.) to calculate the coordinate of center point PressF4 (Save) to save data	F4 F4	Coord. → S m N 10.683 m E 4.169 m Z 9.285 m Back Save
⑥Input Point name and Code	F4	Save $ABC \rightarrow$ $\begin{tabular}{ c c }{ c c } \blacksquare$ Pt NCodeBackCallOKSave $ABC \rightarrow$ Pt NDATE_1CodeABCD

8.5 Missing Line Measurement (MLM)

Measurement for horizontal distance (dHD), slope distance (dVD), elevation relative(dVR) and horizontal bearing (HR) between two target prisms.

It is possible to enter the coordinate value directly or calculate from coordinate data file.

MLM Mode has two modes:

1. MLM-1 (A-B, A-C): Measurement A-B, A-C, A-D

2. MLM-2 (A-B, B-C): Measurement A-B, B-C, C-D



[Example] MLM-1 (A-B, A-C)

Procedure of MLM-2 (A-B, B-C) mode is completely the same as that of MLM-1 mode.

Operation procedure	Operation	Display				
① Press MENU key Press the 1 key, choose a file to enter MEAS PROGRAMS	1	Collect → Imega 1. Collecting 2. Dist. offset 3. Plane Mea. 4. Column Mea. 5. MLM 6. REM				
② Press the 🖥 (MLM) option	5	MLM → 8 m ← 1. MLM1[A-B A-C] 2. MLM2[A-B B-C] Back				

		<u>MLM</u> 123 → § 🖾 🚥 Start
(3) Press	Ш	End Meas. Call Input Cal.
④ Input start point name. Eg:	Input	MLM ABC→ 🗟 🛅 🚥 Start 🗛
A	character	End Meas. Call Input Cal.
⑤ Aim prism A, and press the F1 (MEAS) key	F1 (MEAS)	Coord. Meas. 123 → Imm R. HT 0.000 m N 10.789 m E 4.449 m Z 9.288 m Meas. Back 0K
⑥ PressF4 to return step ⑤, then input end point name, Eg:B	Press F4, then press keyboard	MLM ABC→ S □ =
⑦ Aim at prism B and press the 1 (MEAS) key	F1 (MEAS)	Meas. Call Input Cal. Coord. Meas. 123 → ③ ● ● R. HT 0.000 m m N 12.392 m E 3.328 m Z 9.228 m Meas. Back OK

⑧ Press F4	F4	MLM 123 → 8 m ← Start @Meas. End @Meas. Meas. Call Input Cal.
④ Press F4 (Calculate) key. HD, VD and SD between A and B will shown as picture	F4	MLM → S □ HA 325° 03′ 30″ HD 1.956 m VD -0.060 m SD 1.956 m Cancel Next
 10 Measure the distance between points A and C, press F4 (Next) key*1) 	F4	MLM 123 → 8 m ← End Meas. Call Input Cal.
①Input end point name, Eg: C	Press F4	MLM ABC→ S I ←
^① Aim at prism C and press the 데 (MEAS) key	F1	Coord. Meas. 123 → E Im R. HT 0.000 m N 12.882 m E 4.294 m Z 9.257 m Meas. Back OK

			М	LM	123 →	8
(3) Press F4	F4		End @Meas.			
			Meas.	Ca11	Input	Cal.
4 Press F4 (Calculate) key. HD,			M	LM	→	
VD and SD between A and C			H	A 355	°47′30	"
will be shown	F4		HI)	2.09	9 m
will be shown	14		VI)	-0.03	1 m
			SI)	2.09	9 m
			Cancel			Next
(15) Measure the distance						
between points A and D,						
repeat procedure (10) to (14) *1)						
*1) Press the ESC key to return to	previous surfa	ce				

HOW TO USE COORDINATE DATA

It is possible to input coordinate values directly or calculate from a coordinate data file.

[Example] Input the data (NEZ) directly:

Operation procedure	Operation	Display				
① Press the F3(Input) key	F3	Input Coord. 123 → S Im N 0.000 m E 0.000 m Z 0.000 m Back 0K				

		MLM 123 → 🗟 🛅 🛲
2 Press F4 (coordinate) key	F4	Start @input
		End
		Meas. Call Input Cal.
③ Input the end point,		Start @input
continue to measure		End B
		Meas. Call Input Cal.

*To return to Menu, press the ESC key.

8.6 Remote Elevation Measurement (REM)

To obtain elevation of the point where setting the target prism is not possible, place the prism at any point on the vertical line from the target then carry out REM procedure as follows.



1)With prism height (h) input

Operation procedure	Operation	Display				
	MENU	Collect → 🗟 🗒 🖛				
(1) Press the MENU choose a	_	3. Plane Mea. 4. Column Mea.				
file to enter REM program	1	5. MLM 6. REM				
	6	Back				
		REM 123 → 🗟 🛅 🛲				
		R. HT 0. 000 m				
② Move the cursor to R.HT		VA 30° 38′ 25″				
input		HD m				
mput						
		Meas.				

			R	EM	123 -) 🗟 🗒 🖛	1
			R. H	T 1.25		ш	
	Input prism		V.	A 30)°38′3	4″	
③ Enter prism height *1)			Н	D		m	
	height		V	D		Ш	
				Z		ш	
			Meas.				
			R	EM	123 -	<mark>) 🗟 🖛</mark>	<u> </u>
			R. H	T 1.25		m	
			V.	A 30)°38′3	4″	
④ Aim at prism	Aim P		Н	D		ш	
			V	D		m	
				Z		m	
			Meas.				
			RE	M	123 →	8 🛅 🛲	
(5) Press the F1 (MEAS) key,			R. HT	1.25		m	
measurement starts. Index	F1		VA	. 11	°23′30)″	
value between instrument			HD		2.95	i6 m	
value between instrument			VD		1.75	51 m	
and prism will be shown			Z		0.09	94 ш	
			Meas.				
			RE	EM	123 →	<u> </u>	
			R. H1	1.25		m	
6 Aim target K. the elevation	A inte 14		VA	. 30	* 38 ′ 34	1″	
(7) will be shown, *2)	AIM K		HD)	2.9	56 m	
(1)			VD	1	1.78)1 m	
			<i>L</i>	,	1.28	о 0 ш	
			Maga				
			Meas.				
*1) Refer to 2.10 "How to Enter	r Alphanumeric (Charac	Meas. ters".				
 *1) Refer to 2.10 "How to Enter *2) To return to COLLECT Menu 	r Alphanumeric (1, press the ESC)	Charac key.	Meas. ters".				

2)Without prism height input

Operation procedure	Operation	Display
① Press 1 key, enter the COLLECT menu	Д	Collect → ⑧ 1. Collecting 2. Dist. offset 3. Plane Mea. 5. MLM 6. REM Back Image: State
② Press 6 key, enter REM	6	REM 123 → Image: Control in the second sec
③Aim the prism and press F1 (MEAS) and start measurement. Index value between instrument and prism will be shown	Aim target	REM 123 → Imm R. HT 0.000 m VA 279° 41′ 07″ HD 0.522 m 0.089 m Z 0.000 m Meas. 0.000 m
④ Aim target K, the elevation (Z) will shown.	Aim K	REM 123 → E Im R. HT 0.000 m VA 285° 05′ 31″ HD 6.844 m VD 1.846 m Z 0.000 m Meas.

9.Stake Out

The Stake Out mode have two functions, measuring the location of the stake out point and stake out by the known coordinate from internal memory.

The coordinate data is stored in a COORD. DATA file.For internal memory, please refer to Chapter "DATA"

*1) Please confirming that the instrument is in the main menu or angle measurement mode when power off. It will make sure that the whole process of data import and export already done, also prevent the data lost.

*2) It is recommended for safety to fully charge the batteries before operation.

*3) Please consider whether the internal memory is enough for recording new points.



For Stake out procedure as below:

- 1. Choose coordinate data file
- 2. Set station point
- 3. Input or call the needed Stake-Out coordinate, and start.

9.1 Choose data file

In stakeout mode, you should choose a coordinate data file first, which will be used for station point and data calling. Also the new measured data can be saved in selected coordinate data file.

When stake out mode is operating, you can select file in the same way.

Operation procedure	Operation	Display
①Press <mark>2</mark> (Stake Out) from main menu	2	Main menu → Image: Constraint of the system 1. Collect 2. Stake Out 3. Calculation 4. Program 5. Set Stn 6. Data 7. Setting 8. Adjustment Back Time Info
 ②Scroll the file list or new built file by pressing the [▲] or [▼] key. PressF4 (OK) to enter stake out page 	F4	Call file → Imega 16062200 - 16062101 - 28 - Back New Find OK S0 -> Imega 1. Coord. S0 2. Ang/dist. S0 3. RefL S0

9.2 Coordinate stake out

The coordinate of stake out point can be input in two methods:

1. Built new coordinate point or input coordinate point

2. Call from the coordinate data file

For example: Call coordinate from the coordinate data file.

Operation procedure	Operation	Display
① Press 1 (coordinate stake	ก	Coord. S0 123 → 🗟 🛅 🖛
		Pt N
out) key .		R. HT 0.000 m
		Input New Call SO
		Coord. data → 🗟 🖾 🖛
	ED	1 DATE_1
(Z) Press F3 (Call)	F3	
		\rightarrow
	F1	$\begin{array}{c c} \hline \hline \\ $
③Choose points from coordinate data, press F1 key to check coordinate		Pt N DATE_1
		Code ABCD
		N 9.371 m
		Z 9.341 m
		Back OK
④Press F3 (OK)	F3	Coord. SO 123 🛶 🗟 🛅 🛲
		Pt N DATE_1
		R. HT 0.000 m
		Input New Call SO

		Adjust HA 🚽 🗟 🛛	
⑤Press F4 (SO) to start stake-out	F4	HA 52°18′41″	
		HAD 181°43′12″	
		Azimuth 230°35′29″	
		HD 0.991	m
		Cancel Ne	xt
		Adjust HA 🚽 🗟 🛛	b
		HA 129°24′32″	
		HAD 0°00′01″	
6 Adjust the leveling screw to		Azimuth 129°24′31″	
make the HAD(Horizontal angle	Move level	HD 0.991	m
difference) become value 0	screw	Cancel Ne	xt
difference) become value 0,	F4	Coord. S0 - 거 🖲 🗄	<mark>) —</mark>
then press F4	F1	Left 0°00′01″	
Press F1 (Meas.)	<u>· -</u>	Far/near	m
		L/R	m
		fill-cut	m
		Meas. Cancel 1/3 Char	nge
		Coord. S0 🚽 🗟 🖫) 💶
		Left 0°00′01″	
		N 9.139	ш
		E 6.048	m
		Z 9.294	ш
⑦PressF3 (1/3) to switch	5	Meas. Cancel 2/3 Char	ige
	F3	Coord. SO 🚽 🗟 🖩) 💶
		Left 0°00′01″	
		North 0.232	m
		West 0.282	m
		Up 0.047	m
		Meas. Cancel 3/3 Char	ige
8 When all value become 0,			

the test built of layout point		
has completed		
		Coord. S0 123 → 🖲 🛅 🖛
③Press F4 (change) key, into next point stake-out	F4	Pt N
		R. HT 0.000 m
		Input New Call SO

9.3Angle/distance stakeout

Angle/distance stakeout can be carried on by inputting the relative position relation between stakeout point and station point.

Operation procedure	Operation	Display
		Ang/dist.S0 123 → 🗟 🛅 🖛
	Innut	Azimuth O
(1) Input angle, distance,		HD 50 m
vertical distance		VD 2.2 m
		R.HT 1.500 m
		Back SO
②Press F4 (SO) to start stake out	o start stake F4	Adjust HA 🚽 🗟 🛅 🚥
		HA 129°24′32″
		HAD 129°24′32″
		Azimuth 0°00′00″
		HD 50.000 m
		Cancel Next

		Adjust HA 🚽 🗟 🛅 🖛
		HA 129° 24′ 32″
		HAD 129°24′32″
(3)Adjust the leveling screw to		Azimuth 0°00′00″
make the HAD/Herizental angle	Move level	HD 50.000 m
	screw	Cancel Next
difference) becomes value 0,	F4	Coord. S0 → 🗟 🛅 🛲
then press F4	F1	Left 0°00′00″
PressF1 (Meas.)	FI	Far/near m
		L/R m
		fill-cut m
		Meas. Cancel 1/3 Change
		Coord. SO -> 🗟 🖾 🖛
		Left 0° 00′ 00″
		Far 49.926 m
④ Press F3 (1/3) to switch		Left 0.000 m
—		Fill 2.305 m
	F 2	Meas. Cancel 1/3 Change
when all value become 0, the	F3	Coord. SO 🚽 🗟 🖽 💳
test built of layout point has		Left 0°00′00″
completed		N 10.074 m
		E 5.000 m
		Z 5.895 m
		Meas. Cancel 2/3 Change
		Ang/dist.S0 123 → 🗟 🗒 🛲
~ —		Azimuth 🚺
(6) Press F4 (change), into next	F4	HD 0.000 m
stakeout point		VD 0.000 m
		R.HT 1.500 m
		Back SO

9.4 Reference Line Stakeout

Reference line stakeout is a new developed module of N3 series, the target point will be stake out by comparing the distance relation between stakeout point and the line connected by two known points.

Operation procedure	Operation	Display
① Press the <mark>3</mark> (Refl. SO) key from the stakeout menu	З	RefL S0 123 → Image: Contract of the second s
②PressF2 (call)	F2	Coord. data → Image:
③Choose the point from coordinate data, view the details then pressF3(OK)	Ρ1	Coord. list → Image: Coord list Pt N DATE_1 Code ABCD N 9.371 m E 5.766 m Z 9.341 m Back 0K
For example: P1 choose point name DATE_1 P2 choose point name DATE_2	F4	Coold. Hist <

	Ρ2	RefL S0 123 → E Image: Contract of the second secon
④PressF4 (Next)	F4	RefL S0 123 → S Im L-R+ 0.000 m F+B- 0.000 m U+D- 0.000 m P1->P2 Next
⑤Input setting out point, start from P1, P1P2 as the datum	keypad	RefL SO $123 \rightarrow$ Image: Constraint of the second secon
⑥ PressF4(Next) to enter stakeout page	F4	Adjust HA → B ■ HA 0° 00′ 00″ HAD -183° 39′ 33″ Azimuth 183° 39′ 33″ HD 2.665 m Cancel Next

		Adjust HA 🚽 🗟 🛅 🛲
		HA 183°39′34″
		HAD 0° 00′ 00″
⑦ Adjust leveling screw to	Move	Azimuth 183°39′33″
make the HAD value becomes	leveling	HD 2.665 m
		Cancel Next
0, then press F4	screw	Coord. S0 🚽 🗟 🕮 🛲
	F4	Left 0°00′00″
Press F1 (Meas.)	F1	Far/near m
		L/R m
		fill-cut m
		Meas. Cancel 1/3 Change
		Coord. S0 🚽 🗟 🛅 🛲
		Left 0° 00′ 00″
		N 9.927 m
⑧PressF3 (1/3) to switch		Е 4.995 ш
		Z 5.896 m
When all value become 0, the	F 2	Meas. Cancel 2/3 Change
when all value become 0, the	F3	Coord. SO 🚽 🗟 🖫 🛲
test built of layout point has		Left 0°00′00″
completed		South 2.587 m
		West 0.165 m
		Up 6.445 m
		Meas. Cancel 3/3 Change
		RefL S0 123 → 🗟 🛅 🚥
		L-R+ 0.000 m
Press (change) key, into next	E4	F+B- 0.000 m
stake-out point	<u>F4</u>	U+D- 0.000 m
		P1->P2
		Cancel Next

10.Calculation

Calculation menu operation procedure



10.1 Cal.XYZ(Coordinate Calculation)

Input or measure starting point, then get the coordinate of target point by measuring the azimuth, horizontal distance and vertical elevation.

The coordinate of starting point has two ways to input:

- 1. Built new coordinate point or input coordinate point
- 2. Call from the coordinate data file

For example: Get the coordinate of new point by measurement

Operation procedure	Operation	Display
① Press1 (Cal. XYZ) from Calculation menu	1	Cal. XYZ 123 → S m Start
② Input azimuth, horizontal distance, vertical distance	keypad	Cal. XYZ 123 → § Im Start @input Azimuth 12.5324 HD 100 m VD 10 m Cal. Cal.
③PressF4 (Cal.)	F4	Coord. cal. → S ■ N 97.480 m E 22.308 m Z 10.000 m Back Save
④ PressF4 (Save) to save the data of the point	F4	Save ABC→ 🗟 🛅 🖛 Pt N 06 Code ABCD
--	----	---
		Back Call OK

10.2 Coordinate inverse calculation

Input or measure the starting point and end point, then the instrument can calculate the HD(horizontal distance), SD(slope distance), VD(vertical distance) and azimuth for the line connected by the two points.

The coordinate of starting point and end point have two ways to input:

- 1. Built new coordinate point or input coordinate point
- 2. Call from the coordinate data file

For example: Get the coordinate of new point by measurement

Operation procedure	Operation	Display
① Press 2 (inverse) key from	2	Inverse 123 → 🗟 🛅 🚥
Calculation menu		End Meas. Call Input Cal.
② Press F1 (Meas.) start point Press F4 (OK)	F1	Coord. Meas. 123 → E Imm R. HT [0.000] m N 9.926 m E 4.995 m Z 7.396 m Meas. Back 0K

		Coord. Meas. 123 → 🗟 🛅 🛲
		R. HT 0.000 m
		N 9.544 m
		Е 4.846 m
		Z 7.351 m
3 Repeat step 2 to measure		Meas. Back OK
end point		Inverse 123 → 🗟 🖫 🛲
		Start @Meas.
		End @Meas.
		Meas. Call Input Cal.
④ PressF4 (Cal.)		Cal. result → 🗟 🖾 🖛 Azimuth 201°18′30″
		HD 0.410 m
	F4	SD 0.412 m
		VD -0.045 m Slana 0.110:1
		0.110.1 0K

10.3 Area/ Perimeter

The area and perimeter of graph which composed by those measured points can be calculated by measuring 3 or 3 more points.

Operation procedure	Operation	Display
①Press <mark>3</mark> (Area and Perimeter.) from calculation	3	Area calculation → 🖲 🕮 🖛 ← → Add Delet Cal.

		New Pt 123 -> 🗟 🛅 🛲
②Press F1 (Add)	F1	Pt N
③PressF1 (measure)	F1	Coord. Meas. 123 → 8 m R. HT 0.000 m N 9.572 m E 4.853 m Z 7.360 m Meas. Back 0K
④PressF4 (OK)	F4	New Pt 123→ 8 🕮 🖛 Pt N @Meas. Meas. Call Input OK
⑤PressF4 (OK)	F4	Area calculation → S Image: Calculation 1 @Meas. ← 3 @Meas. ← Add Delet Cal.
⑥Repeat step ②and⑤ to measure other new add point		Area calculation → ● ■ 1 @Meas. ← 2 @Meas. ← 3 @Meas. ← Add Delet Cal.

		Cal. result	→ 🗟 🖫 🕇
⑦PressF4 (Cal.) F4	Area	2.073 m2	
		Girth	6.647 m
			OK

10.4 Point to Line Inverse

Measure 2 starting points P1 and P2 to define a straight line at first, then measure a setting point P3, you can get the coordinate of foot point from P3 to the straight line at last.

The coordinate of each points has two ways to input:

- 1. Built new coordinate point or input coordinate point
- 2. Call from the coordinate data file

Operation procedure	Operation	Display
①Press4 (Pt to line inverse)key from calculation menu	4	to line inverse c 123 → 🗟 🛅 🛲 Sta PtP1
②PressF1 (measure) P1	F1	Coord. Meas. 123 → B Im R. HT 0.000 m N 6403.477 m E 13.822 m Z 2.200 m Meas. Back 0K

③PressF4 (OK)	F4	to line inverse c 123 → 🗟 🛅 🖛 Sta PtP1 @Meas. Sta PtP2 Off PtP3 Meas. Call Input Cal.
④Repeat step ②and③ to measure P2 and P3	F4	to line inverse c 123→ 🗟 🛅 🖛 Sta PtP1 @Meas. Sta PtP2 @Meas. Off PtP3 @Meas. Meas. Call Input Cal.
⑤Press F4 Cal.	F4	Cal. result → ⑧ □ ■ N 6395.827 m E 11.639 m Z 0.277 m P1-P4 8.415 m P3-P4 1.490 m Back Save
⑥Press F4 (Save)	F4	Save 123 → E III Pt N
⑦Input this point's name and coordinate, pressF4 (OK)	F4	Save ABC→ B ■ Pt N 123 Code ADG Back Call OK

11. PROGRAM



11.1 Road

In ROAD program, you can define a curve formed by straight line, circular curve or transition curve as a reference to take measurement and stake out. The program will take coordinate calculation and stake out to designed point according to the confirmed stake number and difference of road design.

Before road design and stake out, you should set the project, station point and back-sight azimuth.

Operation procedure	Operation	Display
① Enter the road program from menu	A	Program → B □ 1. Road - - - Back - - - Road select - - - 1 - - - 2 - - - 3 - - - 4 - - - 5 - - - New Delete Edit OK
②Press [▲]or[▼] to choose road or built new road. PressF4 (OK) enter road page	F4	Road → Image: Constraint of the second sec

11.1.1 Horizontal Alignment Data

Horizontal Alignment Menu

HZ AL	→ 🗟 🛅 🖛
1.Define HZ AL	
2.Edit HZ AL	
3.Import HZ AL	
4.Clear HZ AL	
Back	

Horizontal alignment consisted of following elements: starting point, straight line, circular curve, transition curve.

Straight line

When the starting point or other line type is well defined it allows you to define a straight line. A straight line parameter only include length, the value should larger than zero.



Circular Curve

Press $\boxed{F2}$ key (ARC) in the "HZ AL Screen" to define a circular curve. Circular curves consists of Arc length and the Radius. The radius value rule: Looking along the forward direction of the curve, when the curve rotates to right, the radius value is positive. When the curve rotates to left, the radius value is negative.

input parameter :arc length,radius



circular ares

Transition curve

Press $\boxed{F3}$ key in the "HZ AL Screen" and a transition curve can be defined. The inputting of transition curve consists of transition curve parameter "Para", starting radius, and ending radius. If the input radius is ∞ you can input 0 as its value.

When Rs and Re value is positive, transition parameter A is symbolic number.

The rule of transition curve parameter A : Looking along the forward direction of the curve. When the curve rotates to right, the radius value is positive. When the curve rotates to left, the radius value is negative.

input, parameter: radius R1, radius R2, parmeter of a curve(A)



transition curve

Operation procedure	Operation	Display
① Enter define horizontal alignment, if it is not defined, the display will show the start point page	<u>1</u> Enter	Start 123 → B ■ StakeNo. 200 m Azimuth 12.2352 m N 2136.235 m E 5214.322 m
②Enter alignment data input page by press (OK) key	F4	HZ AL → S Image: Constraint of the second s
	Strl	StrL 123 → 🗟 🛅 🖛 L 50 m Back 0K
③Choose different alignment to input, then finish the horizontal alignment design	C-curve	Circle curve 123 → 🖲 📾 🖛 Radius 30 m ArcL 200 m Back 0K
	T-curve	Transition curve 123 → 🗟 🛅 🖛 Para. 50 S radius 600 m E radius 800 m Back 0K

Edit horizontal alignment

Operation procedure	Operation	Display
①Choose 2 in HZ AL surface. Enter edit horizontal alignment	2 Enter	HZ AL → S 1 S Pt 2 StrL 3 C curve 4 T curve No. 1 Last Find Detail
② Choose the horizontal alignment to check and edit.	Choose F4	HZ AL → 200.000 m StakeNo. 200.000 m Azimuth 12° 23′ 52″ N 2136.235 m E 5214.322 m Back StrL C-curve T-curve

Import horizontal alignment

Operation procedure	Operation	Display
		Data import 123 → 🗟 🖽 🚥
Enter import horizontal alignment	Enter	File
		Back Call OK

Clear horizontal alignment

Click to CLEAR to delete all the saved horizontal alignment data.

11.1.2 Vertical Alignment Data

Vertical Alignment Menu

VT AL	→ 🗟 🗒 🛲	
1.Define VT AL		
2.Edit VT AL		
3.Import VT AL		
4.Clear VT AL		
Back		

A vertical curve consists of series of intersection points. The intersection point consists of a stake number, elevation and curve length. The start/end points and end curve length must be a zero.



Edit Vertical Alignment

Operation procedure	Operation	Display
①Enter edit vertical alignment	2	VT AL → Image: Second
② You can find/check the		VT AL - 🚽 🗟 🛅 🛲
inputted vertical alignment		1 20.000 2 40.000 ←
data, also can edit when you		3 60.000
enter check detail		→
information		No.1 Last Find Detail

Import Vertical Alignment

Operation procedure	Operation	Display
① Enter define vertical alignment	В	VT AL → B ■ 1. Define VT AL 2. Edit VT AL 3. Import VT AL 4. Clear VT AL
②Finish the design of vertical alignment by import data		Data import 123 → 🕄 🛗 🛲 File 📃 Back Call OK

Clear vertical alignment

Click to CLEAR to delete all the saved vertical alignment data.

11.1.3 Road Stake Out

For the road stake out, the line type must be defined. Horizontal and vertical alignment can be defined according to the procedures in the previous sections.(If it does not need to fill or cut, user does not need to define the vertical alignment)

Offset Left: the HD between left stake and center line Offset Right: the HD between right stake and center line VD Left : the VD between left stake and center line VD Right : the VD between left stake and center line



Operation procedure	Operation	Display
 Enter Road SO program, input start stake-No., interval, difference and vertical distance, then enter next step 	З	Road S0 123 → B Im S stake 2000.000 m Spacing 0.000 m Back Next
② Show the stake-No. and difference information of stakeout point, press F4(Next) to start	F4	Road S0 123 → S Im StakeNo. 0.000 m Diff. 10 m VD 1.2 m R.HT 1 m Back +PEG -PEG Next
③ Show the information of stakeout point. Press F4(Next) to start stakeout	F4	S0 coordinate → Image: Coordinate N 2134.088 m E 5224.089 m Z 7.200 m Back Next
④Start stakeout		Coord. S0 → Image: Coord. S0 Left 56° 10′ 26″ Far/near m L/R m fill-cut m Meas. Cancel 1/3

11.1.4 Calculation

Single-point coordinate calculation

Operation procedure	Operation	Display
Enter single-point		Single Pt cal. 123 → 🗟 🖫 🛲
coordinate calculation, input		Mileage 12 m
mileage and point name,	F4	
instrument will calculate		Pt N 25
automatically and save it		Back OK

Batch coordinate calculation

Operation procedure	Operation	Display
Enter batch coordinate		Batch cal. 123 → 🗟 🖽 🚥
calculation, input mileage		S stake 0.000 m
and point name, instrument	F4	E stake 100.000 m
will calculate automatically		Spacing 10 m
win calculate automatically		Pt N 25
and save it		Back Cal.

11.1.5 Road select

In the Road select, the selected road is the current operating road file.

Operation procedure	Operation	Display
Enter road select page, choose the road file, then press (ENT) confirm and exit	Enter	Road select → B m 1 - 2 - 3 - 4 - 5 - New Delete Edit

12.Set Station

Select a coordinate data file before enter setting a station, used for station measurement and data calling. It can also save the data of new point into the selected coordinate data file.

Operation procedure	Operation	Display
① Press 占 (Set Stn) from the menu	5	Main menu → Image: Constraint of the system 1. Collect 2. Stake Out 3. Calculation 4. Program 5. Set Stn 6. Data 7. Setting 8. Adjustment Back Time Info Call file → Image: Constraint of the system 16062100
②Choose the correct file and press F4 (OK) to enter setting station page	F4	Set Stn → Image: Constraint of the section 1. Known Pt 2. Resection 3. Pt to line 4. Elevation transmit 5. BS check Back

12.1 Known Point

Station point and back-sight point can be set by two ways:

- 1) Call the coordinate setting from internal memory
- 2) Directly input the coordinate data or create new coordinate data
- *Station coordinate be saved in the selected coordinate data file

Eg: Set station point from the internal coordinate data file.

Operation procedure	Operation	Display
① Press 1 (Known Pt) from the set station menu	1	Stn Pt 123 → S IIII Pt N
② PressF3 (Call)	F3	Coord. data → Image: Coord. data 1 006 2 9 3 01 4 03 Detail Find 0K 1/2
③ Choose a point and press F3 (OK)	F3	Stn Pt 123 → E Im Pt N 03
④Press F4 (Next) to forward back-sight select	F4	BS select → 2 mm = 1. Coordinate 2. Angle Back

*There are two different choose of back-sight

1) Coordinate

Operation procedure	Operation	Display
		BS Pt 123 → 🗟 🛅 🛲
	1	Pt N
①Press1 to select coordinate		Code
		R. HT 1. 000 m
		Input New Call Next
		Coord. data → 🗟 🛅 🛲
	F3	1 006
(2) Press F3 (Call)	_	3 01
(,		4 03
		Detail Find OK 1/2
		BS Pt 123 → 🗟 🛅 🛲
	F3	Pt N 01
③Press F3 (OK)		Code
		R.HT 1.000 m
		Input New Call Next
		Aim target → 🗟 🖽 🛲
	F4	Ani-uth 152° 26' 05"
(A) Droce Ed (Novt)		AZIMUTN 193 20 09
(4) FIESS [F4] (NEXL)		HA 152° 37' 14"
		Orient

	F4	Aim target → 🛐 🛅 🛲 Azimuth 239°47′48″
(3) Press <u>r-4 (</u> Unient) key		HA 239° 47′ 48″ Meas. 0K
⑥PressF1 (Measure) key if need	F1	BS Meas. → 🖲 🛅 🛥 Azimuth 153°26′05″ Angle Dist. Coord.
⑦Press F1 (Angle), F2 (Dist.), F3 (Coord.) to get the results, then finish the measurement.		

2) Angle

Operation procedure	Operation	Display
	2	Ang orientation 123 → 🗟 🛅 🚥
①Press团 to select angle		Azimuth
		R. HT 1.000 m
		Cancel Next

②Input azimuth	keyboard	Ang orientation 123 → Image: Cancel Azimuth [120.1212] R.HT [1.000] m
③PressF4 (Next)	F4	Aim target → S Im Azimuth 239° 47′ 48″ HA 0° 00′ 01″
④PressF4 (Orient)	F4	Aim target → Image: Image Azimuth 239° 47′ 48″ HA 239° 47′ 48″ Meas. 0K
⑤PressF1 (Meas.) if needed	F1	BS Meas. → 🗟 🖾 🖛 Azimuth 239°47′48″ Angle Dist. Coord.
 6 Press F1 (Angle), F2 (Dist.), F3 (Coord.) to get the data,then finish the measurement. 		

12.2 Resection

The location of a new point can be determined by observing up to a maximum of seven known points.

*Resection by distance measurement: 2 or more points must be measured, the angle between two points should not exceed 180°.

The station point coordinate value will be calculated using the least squares method. (except in the case of 3 known points measured by angle measurement only).



Operation procedure	Operation	Display
①Enter resection function	2	Resection 123 → E Imm Pt1 25 m R.HT 0.000 m Azimuth 239° 47′ 48″ HD m SD m Dist. 0K

② Input Point name and prism height, then press Dist. key to get the result	F3	Resection 123 → S Imm Pt1 225 m R.HT 0.000 m Azimuth 239° 47' 48" HD 4.257 m SD 4.524 m Input Call Dist. 0K
③Press F4 (OK) key to complete the measurement of first point	F4	Resection 123 → 28 1100 PT2 @input
(4) Repeat step (1) to (3) to measure several points, it can calculate automatically and show the result once meet the calculation condition, also can check and save the result		Resection 123 → 20 123 → 20 N 101.000 ■ E 26.500 ■ Z 31.400 ■ Add Detail Save 1/2

12.3 Point to Line Measurement

This mode is used to obtain the coordinate data of an unknown occupied point from a known point and a known line. An observation will need to be taken at the known point A(0,0,0) and along the line N designated for the example as B. After measuring the 2 points the coordinate and the direction angle of the instrument will be calculated and recorded.



④ Press F1 (Meas.) , measure the distance from point B to station point	F	Meas. P2 123 → B Im R. HT 0.000 m HD 5. 723 m VD 1. 527 m SD 5. 923 m Meas. Cancel Next
⑤Press F4	F4	Pt to line 123 → 2 mm Pt N
⑥ Press F2 (Coord.) to check station point coordinate. Input the point name to save the coordinate.		Coord. → N -3.120 m E 0.168 m Z -0.833 m Back

12.4 Elevation Transmit

This mode is used for adjust the elevation of station point , calculate the elevation of station point by measuring a coordinate of known point.

There are two ways to input the coordinate of known point

- 1) Create a new coordinate point or input coordinate point
- 2) Call the point coordinate from the file

Eg: Call the point coordinate from the file

Operation procedure	Operation	Display
①Press 🛿 (Elevation transmit) from set Station menu	4	Elevation trans. 123 → ⑧ m Known Pt R.HT 0.000 m Input New Call Next
②Press F3 (Call)	F3	Elevation trans. 123 → ⑧ 🖾 🚥 Known Pt 01 R.HT 0.000 m Input New Call Next
③Press F3 (OK)	F3	Coord. data → Image: Second
④Press F4 (Next)	F4	Elevation trans. → 🖲 🕮 🖛 HA 209°49′26″ VD m HD m Meas. Cancel OK

		Elevation trans. 🚽 🗟 🖫 🕶
⑤Press F1 (Meas.)		HA 209°49′26″
	F1	VD 0.827 m
		HD 3.093 m
		Meas. Cancel OK
⑥Press F4 (OK) to get the		Stn 123 → 🗟 🛅 🛲
		Pt N 03
		Inst. Ht 0.000 m
		N 10.000 m
elevation of new station point		N 10.000 m E 5.000 m
elevation of new station point		N 10.000 m E 5.000 m Z -0.827 m
elevation of new station point		N 10.000 m E 5.000 m Z -0.827 m Cancel 0K

12.5 Back-sight Check

Operation procedure	Operation	Display
①Press 🛿 (BS check) from Set Stn menu	5	BS check → ⑧ ■ BS angle 120° 12′ 12″ HA 209° 49′ 26″ HAD 29° 58′ 22″ Exit Reset
② Press F4 (Reset) key to reset the horizontal angle	F3	BS check → B m m BS angle 120° 12′ 12″ HA 239° 47′ 48″ HAD 0° 00′ 00″ Exit Reset

13.DATA

Data collect menu operation:



13.1 File Management

13.1.1 Deleting a File

Operation procedure	Operation	Display
①Press 1 (File) from data menu	а	Flie list → B □ ● 16062100 - - - 16062101 - - - Delete New Find Edit
②Press [▲]or[▼] key, choose file which to be deleted	[▲]or[▼]	Call file → S ■ 16062100 - 16062101 - Back New Find OK
③PressF1 (Delete)	F1	Confirm → 🗟 🖽 🖛 Delete the selected file? Cancel OK
 ④Press F4 (OK) key to delete this file ⑤Press ESC key to return Data menu 	F4	File list → B Im 16062101 Delete New Find Edit

13.1.2 Built a New File

Operation procedure	Operation	Display
①Press 1 (File) from data menu	Ŀ	File list → E ■ 16062101 Delete New Find Edit
②PressF2 (New)	F2	New job 123→) 🗟 🛅 🛲 Job Name 📃 Back OK
③Input the Job Name	keyboard	<u>New job</u> 123→ 🗟 🛅 🖛 Job Name [13] Back 0K
④PressF4 (OK) key to finish the new job	F4	File1ist → E ■ 13 16062101 Delete New Find Edit
⑤Press ESC key to return the data menu		

13.1.3Find a File

Operation procedure	Operation	Display
①Press 1 (File) from data menu	1	Filelist → B ■ 13 16062101 Delete New Find Edit
②Press F3 (Find)	F3	File N Back OK
③Input File name	keyboard	Find 123 → Image: Control in the second se
④Press F4 (OK) to find the file	F4	Filelist → 13 16062101 Delete New Find Edit
⑤Press ESC to back to data menu		

13.1.4 Edit File

Operation procedure	Operation	Display
①Press] (File) from data menu	l	Filelist → 2 Image: Constraint of the second secon
②PressF4 (Edit)	F4	Edit 123 → ⑧ ■ FileName III Back OK
③Input the New file name	keyboard	Edit 123 → 8 🛅 🖛 FileName 28 Back 0K
④Press F4 (OK) to finish the Edit	F4	File list → S Immediate 16062101 28 Delete New Find
⑤ Press ESC to back to data menu		

13.2 Measurement Data

Operation procedure	Operation	Display
①Press 2 (Meas. data) from data menu*1)	2	Call file → Image: Call file 16062101 28 Back New Find
②Press F4 (OK) *2)	F4	Meas. data → Image: Constraint of the second seco
③Press F4 (Detail)	F4	Dist. → ම ■ ■ Pt N mms4 Code A SD 1.821 m HD 0.984 m VD 1.532 m Back Edit 1/2
④Press F3 (Edit) to edit point name and code*3)	F3	Edit Pt 123 → ⑧ 🖾 🖛 Pt N 01 Code Back Call 0K
*1) Press F2 (New) to create a r	new file, press F3	(Find) to find the file
*3) Press F2 (Call) to call data		

13.3Coordinate Data

Operation procedure	Operation	Display	
① Press 쥠 (Coord. data) from the menu*1)	В	Call file → B □ 16062101 - 28 - Back New Find OK	
②Press F4 (OK) *1)*2)	F4	Coord. data → E □ 1 006 2 9 ← 3 01 ↓ 4 03 ↓ Detail Find Add 1/2	
③Press F1 (Detail)	F1	Coord. list → Image: Coord list Pt N 006 Code BE N 15.000 m E 25.300 m Z 26.000 m Back Edit 0K	
④ Press F3 (Edit) to edit point name, code and coordinate*3)	F3	Edit coord. 123 → E III Pt N 1	
 *1) Press F2 (New) to create a new file, press F3 (Find) to find the file *2) Press F1 (Delete) to delete data 			
*3) Press F2 (Call) to call data			

13.4Code Data

Operation procedure	Operation	Display	
Press (Code data) from the menu*1)*2)*3)*4)	4	Code data → E Image: Code data 1 ABCD - 2 ABCDE - Delete New Find Edit	
*1) Press F1 (delete) key to delete data			
*2) Press F2 (New) to create a new file, press F3 (Find) to find the file			
*3) Press F3 (Find) to find data			
*4)Press F4 (Edit) to edit data			
Press the $[\blacktriangle] or [\lor]$ to show the next or last point			

13.5 Data Export

Operation procedure	Operation	Display
Press 5 (Data export) from the menu*1)	5	Data export 123 → 🕄 🛅 🛲
		Type Coord. data
		Format Pt. N, N, E, Z, Code
		Back OK
*1)First input the SD card, input	export file nam	e, data type, data type, then press F4 (OK) to
finish.		

13.6 Data Import

Operation procedure	Operation	Display	
Press 🛛 (Data import) from the menu	۵	Data import 123 → B Imm File	
 *1) First input the SD card, input export file name, data type, data type, then press F4 (OK) to finish. *2) Press F2 (Call), can directly call the file from SD card 			

13.7 Memory

Operation procedure	Operation	Display
		Memory status → 🗟 🖽 🚥
Press 7 (Memory) from the		Total 2028 KB
menu, can check the memory	7	Used 5 KB
status of the instrument		Unused 2023 KB
		Back
13.8 Format

Operation procedure	Operation	Display
①Press <mark>8</mark> (Format)from the menu, then press1	8	Format 📑 📼 1.Format internal memory 2.Clean code data Back
② Press F4 (OK) to format memory		Format → Image: Constraint of the sector of the sect
code data	2	Back
④Press F4 (OK) to format memory		Clean code → Image: Clean the code? Back OK

14.SETTING



14.1Measure Parameter

14.1.1Angle Parameter

Operation procedure	Operation	Display
①Press1 (Meas. parameter) from the menu	1	Meas.Para 1. Ang settings 2. Dist. settings 3. Coord. settings Back
② Press (Ang setting) to adjust vertical zero bit, tilt on/off Press F4 (OK) to confirm	1 F4	Ang setting ZO/HO ZO TILT Close Back OK

14.1.2 Distance Setting

Operation procedure	Operation	Display
①Press1 (Meas. Para) from the menu	1	Meas.Para 1. Ang settings 2. Dist. settings 3. Coord. settings Back
②Press 2 (Dist. settings) *1)*2)*3)	2	Dist. setting Immediate 1. TP correction setting 2. Other correction setting 3. Meas. mode setting 4. Target setting Back

		other correction 123 📲 🛲	
(3) Press (other correction	2	Scale 1.000000	
setting) to adjust Scale,		Z 0.000 m	
Elevation.	Fa	TP amend Open	
Press F4 (OK) to finish	F4	K Close	
		Back OK	
*1) Press (1) (TP correction setting), refer to previous Temperature & Pressure setting.			
*2) Press3 (Meas. mode setting), refer to previous Measurement mode select			
*3) Press4 (Target setting), refer to previous Target mode select			

14.1.3 Coordinate Settings

Operation procedure	Operation	Display
①Press1 (Meas. Para) from the menu	1	Meas. Para 1. Ang settings 2. Dist. settings 3. Coord. settings
② Press (Coord. setting) to adjust coordinate order, face left and right coordinate to display mode	3	Coord. setting Image: Coord. NEZ/ENZ N=E=Z L/R Same Coord. Back OK
③Press F4 (OK) to finish	F4	

14.2 Unit Setting

Operation procedure	Operation	Display
①Press 2 (Unit setting) from the menu	2	Unit setting Angle Degree Dist. m Temp. Pressure Back
② Adjust each unit, then press F4 (OK) to finish	F4	

14.3 Serial Comm Setting

Operation procedure	Operation	Display
①Press 国 (Serial Comm) from the menu	3	Comm. settingOn/OffOpenBaudrate9600data bit8 bitsParityNullStop bit1 bitBackOK
② Adjust each option, then pressF4 (OK) to finish	F4	

14.4 Back-light Setting

Operation procedure	Operation	Display
① Press 4 (Back-light) from the menu	4	Power/Backlight 1.Battery management 2.Backlight setting 3.Crosshair backlight Back
	1	Power management Sleep 5 PowerOff 20 B-light 0 Battery Li-ion Back OK
 Press 1 and 2 to adjust each option, press F4 (OK) to finish; Press 3 to enter cross-hair back-light setting, press F4 (OK) to finish. 	2	Backlight Auto Close Double Open Keypad Close Lux 7 Back OK
	З	Crosshair — — on/off Open — ()
	F4	Lux ————————————————————————————————————

14.5 Time/date Setting

Operation procedure	Operation	Display
		Date/Time 123 🗒 🛲
(1) Press 5 (Time/date) from the menu	5	Date 2016. 06. 21
press F4 (OK) to finish	F4	Time 13: 43: 05
		Back OK

14.6 Other Setting

Operation procedure	Operation	Display
① Press 🗗 (others) from the menu	4	Other settings Image: Constraint of the setting 1. Factory reset 2. Voice setting Back Image: Constraint of the setting
② Press 1 and 2 key to adjust	1	Confirm → 🕃 🛅 🖛 Factory reset? Cancel 0K
each option , press <u>F4</u> (OK) key to confirm	2 F4	Voice setting
		Back OK

15.CHECK AND ADJUSTMENT

The instrument has been checked and adjusted thoroughly at the factory to insure the instrument meets our quality requirements. But long distance transportation and the change of the environment could cause the instrument to go out of adjustment. It is recommended before using the instrument it should be checked and adjusted according to the procedures outlined below.

15.1 Plate Vial



Inspection

Refer to Instrument Set Up and "Leveling by using the plate vial"

Adjustment

1. If the bubble of the plate vial moves away from the center, bring it half way back to the center by adjusting the leveling screw, which is parallel to the plate vial. Correct the remaining half by adjusting the screw of plate vial with adjusting pin.

2. Confirm whether the bubble is in the center by rotating the instrument 180°. If not, repeat Step 1.

3. Rotate the instrument 90º and adjust the third screw to center the bubble in the vial.

Repeat checking and adjustment steps until the bubble remains in the center with the vial in any direction.

15.2 Circular Vial

Inspection

No adjustment is necessary if the bubble of the circular vial is in the center after inspection and adjustment of the plate vial.

Adjustment

If the bubble of the circular vial is not in the center bring the bubble to the center by using the adjusting pin or hexagon wrench to adjust the bubble adjusting screw. First loosen the screw opposite to the offset side and then tighten the other adjusting screw on the offset side, bringing the bubble to the center. After the bubble stays in the center each of the three adjustment screws should be tightened in a uniform manner.

15.3 Compensator

After leveling the instrument accurately, the tilt angle should be close to 0, otherwise it exist zero error of tilt sensor, which will affect the measurement result.

Inspection

- 1. Leveling instrument accurately.
- 2. Open the XY in the E bubble page, details refer to 3.3



3. Read compensation tilt angle value X1 and Y1 after the display stable

4.Rotate telescope 180°, read the compensation tilt angle value X2 and Y2 after the display stable



5.Calculate the zero deviation of tilt sensor by using following formula:

Deviation X=(X1+X2)/2

Deviation Y=(Y1+Y2)/2

Adjustment

If the deviation value within ±20", then no need adjustment, otherwise need adjustment as following:

1. Enter Tilt adjustment page in Adjustment function

2.Collimate a target in the right position



3. Press (OK), collimate the same target in the reverse position

Adjustment	→ 🕀 🛅 🛲	
1.TILT Adjustment		
2.VO Adjustment		
3.EDM constant		
Back		

4. Confirm whether the adjustment correction value within the range. If X value and Y value are within the adjustment range, then press F4 (OK) to update the correction value,

otherwise, exit the adjustment operation, and contact with the local dealer.

5.Follow the inspection step 1 to 5 again. If the result with ±20", then the adjustment is over, otherwise, should adjust again. If it is still out of range after 2 to 3 times adjustment, please contact with the local dealer.

15.4 Inclination of Reticle

Inspection

1. Sight object A through the telescope and lock the horizontal and vertical clamp screws.

2. Move object A to the edge of the field of view with the vertical tangent screw (point A^{\prime}).

3. No adjustment is necessary if object A moves along the vertical line of the reticle and point A' is still in the vertical line.

As illustrated A ' offsets from the center and the cross hair tilts, then the reticle needs adjustment.



Adjustment

1. If the object A does not move along the vertical line, first remove the eyepiece cover to expose the four reticle adjusting screws.

2. Loosen the four reticle adjusting screws uniformly with an adjusting pin. Rotate the reticle around the sight line and align the vertical line of the reticle with point A '.

3. Tighten the reticle adjusting screws uniformly, pepeat the inspection and adjustment to see if the adjustment is correct.

4. Replace the eyepiece cover.



15.5 Perpendicularity of Line of Sight to Horizontal Axis (2c)

Inspection

1. Set an object A at a far distance the same height as the instrument, then level and center the instrument and turn on the power.

2. Sight object A in the left position and read the horizontal angle value

(horizontal angle L=10°13 '10").

3. Loosen the vertical and horizontal clamp screws and rotate the telescope. Sight object A in right position and read the horizontal angle value.(horizontal angle $R = 190^{\circ}13'40''$).

4.2 C = L - (R±180°) = - 30" \geq ±20" , adjustment is necessary.



Adjustment

1. Use the tangent screw to adjust the horizontal angle reading.

2. Take off the cover of the reticle between the eyepiece and focusing screw. Adjust the two adjusting screws by loosening one and tightening the other. Move the reticle to sight object A exactly.

- 3. Repeat inspection and adjustment until | 2C | < 20".
- 4. Replace the cover of the reticle.

15.6 Adjustment of Vertical Index Difference (I angle) and Vertical Angle 0 Datum

Inspect the item after finishing the inspection and adjustment of item 15.3 and 15.4.

Inspection

1. Power on after leveling the instrument. Sight object A in left position and read the Verticail angle value L.

2. Rotate the telescope. Sight object A in right position and read the Verticail angle value

R.

3. If the vertical angle is 0° in zenith, $i = (L + R - 360^{\circ}) / 2$

If the vertical angle is 0 ° in horizon $i = (L + R - 180^\circ) / 2$ or $(L + R - 540^\circ) / 2$.

4. If $|i| \ge 10''$ set the Vertical Angle 0 Datum again.

Adjustment

1.After leveling the instrument, enter the adjustment mode:

Adjustment	→ 🕀 🛅 💳
1. TILT Adjustment	
2.VO Adjustment	
3.EDM constant	
Back	

2.Press 2 , in left position rotate the telescope. Precisely sight any target A at the same

height as the instrument, the vertical angle is displayed.

VO Adjustment		⊣€) 🛅 🛑
Step 1 Front			
V:	85° 07′	10″	
Exit			OK
Exit			OK

3.Rotate the telescope and precisely sight the same target A, press F4

	VO Adjustment		→ 🕀 🛅 💳		
	Step 1	Front			
	v	: 85	° 07′	10″	
	Step 2	Reverse			
	v	: 265	° 05′	29″	
	Exit				OK
4.Press F4 , display follow, then press (OK) key to finish.					
				<mark>. →</mark> () 🛅 🛲
	New i: 4°53′40″ Overrun Setting?				
	Cance1				OK

Repeat the inspection steps to measure the Index difference (I angle). If the Index
 Difference does not meet requirements redo the steps above. Please carefully repeat these steps to ensure the proper result.

6. If Index Difference does not meet the requirements after the repeated operation the instrument should be returned to factory for inspection and repair.

15.7 Optical Plummet

Inspection

 Set the instrument on the tripod and place a piece of white paper with two perpendicular lines under the instrument.

2. Adjust the focus of the optical plummet and move the paper so that the intersection point of the lines on the paper comes to the center of the field of view.

 Adjust the leveling screws so that the center mark of the optical plummet coincides with the intersection point of the cross on the paper.

4. Rotate the instrument around the vertical axis and at every 90° observe whether the

center mark position coincides with the intersection point of the cross.

If the center mark always coincides with intersection point no adjustment is necessary.
 Otherwise, the following adjustment is needed.



Adjustment

1. Take off the protective cover between the optical plummet eyepiece and focusing knob.

2. Fix the paper. Rotate the instrument and mark the indicated point of the center of the optical plummet on the paper at every 90°. As illustrated: Point A, B, C, D.

3. Draw lines that attach AC and BD and mark the intersection point of the two lines as O.

 Adjust the four adjusting screws of the optical plummet with an adjusting pin until the center mark coincides with Point O.

5. Repeat the inspection and adjusting steps to be sure the adjustment is correct.

6. Replace the protective cover.

15.8 Laser Plummet

Inspection

1. Set the instrument on the tripod and place a piece of white paper with two perpendicular lines under the instrument.

2. Open the laser plummet, move the paper to make the laser point coincide with the center of two perpendicular lines..

3. Rotate the plummet to make the laser point coincide with the intersection point on the

paper..

4. Rotate the instrument, every 90° check contact ratio of laser point and intersection point.

5. If the laser point always coincided with the intersection point, no adjustment is necessary.

Otherwise, the following adjustment is required..



Adjustment

1. Take off the protective cover

2. Fix the paper and mark the laser point on the paper every 90°. As shown in the picture:

Point A, B, C and D.

3. Line the Point AC and BD, the intersection point is 0.

4. Use Allen Key to adjust the four adjusting screws to make the center of the laser point coincide with point 0..

5. Repeat the inspection and adjusting steps to be sure the adjustment is correct.

6. Replace the protective cover.

15.9 Instrument Constant (K)

The instrument constant has been checked and adjusted in the factor, K=0. It changes seldom and it is suggested to check one or two times every year. The inspection should be made on a base line but also can be made according to the following method.

Inspection

1. Mount and level the instrument on Point A in a flat area. Use the vertical hair to mark

Point B and Point C on the same line with the distance of 50m between each point. Set the reflector accurately on each point when measuring.

2. After setting temperature and air pressure in the instrument measure the Horizontal Distance of AB and AC accurately.

3. Set the instrument on Point B and center it accurately, measure the Horizontal Distance of BC accurately.

4. Then you can calculate the Instrument Constant:K=AC-(AB+BC)

K should be very close to 0, If | K | > 5 mm the instrument should be inspected at a standard baseline site and adjusted according the inspection value.



Adjustment

If a strict inspection proves that the Instrument Constant K has changed the operator can change the constant by entering the adjustment amount. Press 3 in ADJUSTMENT mode and key in the new constant.

EDM constant	123 →	🕀 🛅 💳
SD		ш
HD		ш
VD		m
Prism 🚺		mm
NonPrism 0		шш
Cancel	Meas.	OK

15.10 Parallel between Line of Sight and Emitting Photoelectric Axis



Inspection

- 1. Set the reflector 50m from the instrument.
- 2. Sight the center of the reflector prism with reticle.

3. Power on and enter Distance Measurement Mode. Press MEAS to measure. Rotate the Horizontal Tangent Screw and Vertical Tangent Screw, to do electric collimation and make the light route of EDM unblocked. In the bight zone find the center of emiting photoelectric axis.

 Check whether the center of reticle coincides with the center of emiting photoelectric axis. If so, the instrument is up to grade.

Adjustment

If there is great difference between the center of reticle and the center of emitting photoelectric axis the instrument needs repair.

15.11 Tribrach Leveling Screw

If the leveling screw becomes loose adjust the two adjusting screws in the leveling screw to tighten appropriately.

15.12 Related Parts for Reflector

1. The Tribrach and Adapter for Reflector

The plate vial and optical plummet in the adapter and plate vial should be checked, refer to Session 15.1 and 15.7

2. Perpendicularity of the prism pole

As shown in picture in Session 13.8, mark '+' on Point C, place the tine of the prism pole on the Point C and do not move it during the inspection. Place the two feet tine of Bipod on Point E and F on the cross lines. Adjust the two legs to make the bubble on the prism pole centered.

Set and level the instrument on Point A near the cross. Sight tine of Point C with the center of reticle, and fix the Horizontal Clamp Screw. Rotate the telescope upward to make D near the horizontal hair. Flex the prism pole Leg e to make the D in the center of reticle. Then both Point C and D are on the central line of reticle.

Set the instrument on Point B on the other cross lines. Flex the leg F and make point D on the prism pole overlapped with central line of the point C's cross lines.

Through the collimation on Point A and B, the prism pole has been set perpendicular. If then the bubble deviates from the center, adjust the three screws under circular vial to make the bubble centered, refer to Session 13.2.

Check and adjust again until the bubble is in the center of the vial from both directions.

122

16.Specifications

Model	N31	N3	
TELESCOPE			
image	erect		
magnification	30x		
effective aperture	45mm (distance meter: 47mm)		
resolving power	3"		
field of view	1°30′		
minimum focus	1.5m		
telescope length	152mm		
ANGLE MEASUREMENT			
measuring method	absolute encoding		
diameter of disk	79mm		
minimum reading	0.1"	1"	
detection method	horizontal: dual vertical: dual		
unit	360 DEGREE/400 GON /6400 MIL optional		
vertical angle 0°	Azimuth 0 /	Horizontal 0 optional	
accuracy	1"	2″	
DISTANCE MEASUREMENT			
single prism	3.5km		
triple prism	6km		
sheet	1.2km		
Reflectorless(white) *1	600m		

Model	N31	N3	
unit		m/ft	
accuracy	<u>+(</u> 1+1x10-6·d)mm w/o prism: <u>+(</u> 3+2x10-6·d)mm	<u>+(</u> 2+2x10-6·d)mm ^{**2} w/o prism: <u>+(</u> 3+2x10-6·d)mm ^{**2}	
measuring time (initial)	single fine measure: less than 1.3s; tracking: 0.4s; Repeat: 0.2		
measuring system	basic frequency: 70-150 mhz		
wave length	685nm		
atmospheric correction	auto correction		
atmospheric refraction & earth curvation correction	auto correction. k=0.14/0.20		
reflector constant correction	Input parameter and auto correction		
VIAL			
circular vial	8′/2mm		
plate vial	30″/2mm		
COMPENSATOR			
system	Dual axis Liquid-electric Sensor Compensation		
compensating range	<u>+</u> 4'		
resolving power	1"		
OPTICAL PLUMMET (OR INTERNAL LASER PLUMMET)			
image	erect		
magnification	Зх		

focusing range	0.3m∼∞
field of view	5°
DISPLAY	
type	3.0 inches LCD graphics, colorful and touch screen
INPUT MODE	
type	alphanumeric with numbers keyboard
DATA TRANSFER	
RS232	yes
USB interface	yes
Bluetooth	yes
SD CARD	yes
STORAGE	
SD card	8GB SD card as default
BATTERY	
battery	Li-battery
voltage	7.4V(dc)
operating time	up to 8 hours
OPERATION ENVIRONMENT	
operation temperature	-20℃ ~ +50 ℃
SIZE & WEIGHT	
size	206mm x 200mm x 353mm
weight	6.0kg

17. ERROR DISPLAYS

Error code	Description	Countermeasures
ERROR 01-06	Angle measurement system abnormal	If the error code appears continuously the instrument needs repair.
ERROR 31 ERROR 33	Distance measurement system abnormal	If the error code appears continuously the instrument needs repair.

18. SAFETY INSTRUCTIONS

18.1 Integrated EDM (Visible Laser)

Warning :

Total station with EDM of laser class 3A resp.a-identifiable by :

Warning decal is above the vertical braking screw in Face 1: "Class III Laser Product".

The product is a class 3A laser product in accordance with:

IEC 60825-1:2001 "Radiation safety of laser products".

Class 3A laser products :

Direct beam viewing is always hazardous. Avoid direct eye exposure. The accessible emission limit is within five times the accessible emission limits of Class 2 in the wavelength range from 400nm to 700nm.

Warning :

Direct beam viewing is hazardous for eyes.

Precautions :

Do not stare into the beam or direct it towards other people unnecessarily. These measures are also valid for the reflected beam.

Warning :

Looking directly into the reflected laser beam could be dangerous to the eyes when the laser beam is aimed at areas that reflect like a mirror or emit reflections unexpectedly (e.g. prisms, mirrors, metallic surfaces, windows).

Precautions :

Do not aim at areas that are essentially reflective, such as a mirror, or which could emit unwanted reflections. Do not look through or beside the optical sight at prisms or reflecting objects when the laser is switched on (in laser pointer or distance measurement mode). Aiming at prisms is only permitted when looking through the telescope.

Warning :

The use of Laser Class 3A laser equipment can be dangerous.

Precautions :

To counteract hazards, it is essential for every user to respect the safety precautions and control measures specified in standard IEC60825-1:2001 within the hazardous distance range.

Below is an interpretation of the main points in the relevant section of the standard quoted.

Class 3R laser products used on construction sites and outdoors (surveying, alignment, leveling):

- Only qualified and trained persons should be assigned to install, adjust and operate the laser equipment.
- b) Areas in which these lasers are used should be posted with an appropriate laser

127

warning sign.

- c) Precautions should be taken to ensure that persons do not look directly, with or without an optical instrument, into the beam.
- d) The laser beam should be terminated at the end of its useful beam path and should in all cases be terminated if the hazardous beam path extends beyond the limit (hazard distance *) of the area in which the presence and activities of personnel are monitored for reasons of protection from laser radiation.
- e) The laser beam path should be located well above or below eye level wherever practicable.
- f) When not in use the laser product should be stored in a cool and dry location.
- g) Precautions should be taken to ensure that the laser beam is not unintentionally directed at mirror-like (mirrored) surfaces (e.g. mirrors, metal surfaces, windows) and more importantly, at flat or concave mirror-like surfaces.

* The hazard distance is the distance from the laser at which beam irradiate or radiant exposure equals the maximum permissible value to which personnel may be exposed without being exposed to a health risk.

Products with an integrated EDM of laser class 3R resp. III a has a hazard distance of 1000m (3300ft). After this distance, the laser beam rates as Class 1 (= direct beam viewing is not hazardous).

18.2 Laser Plummet

This instrument is Class2/ II product, Class 2 level products have follows standards: IEC60825-1:1993 "Radiation safety of laser products" EN60825-1:1994+A II :1996 "Radiation safety of laser products" Do not stare at the laser beam or push it to others. Avoiding dangerous.